semelife



SLIGEN2200

2100-Watt Gas Powered Inverter Generator

Portable and Compact Inverter Generator, EPA+ & CARB Compliant



Read this manual carefully before operation. This manual includes important quidance for safety operation.

This Manual contains important safety information and instructions for operating this generator set. PLEASE READ THIS MANUAL CAREFULLY. Failure to do so could result in property damage and/or personal INJURY or DEATH.

Keep this owner's manual handy, so that you can refer to it any time.

This owner's manual is considered a permanent part of the generator and should remain with the generator if resold.

The information and specifications included in this publication were in effect at the time of approval for printing.

All information in this publication is based on the latest product information available at the time of printing. We reserve the right to change, alter and/or improve the product and this document at any time without notice and without incurring any obligation.

No part of this publication shall be reproduced without written permission.

Write down the generator set's serial number and purchase information. Keep this manual and the receipt for future reference.

Model:		 	
Serial number:		 	
Date of purchase	::	 	

CONTENTS

I. Operator safety		4
1. Safety rules •		4
II. Features and controls •	•	8
III. Operating •		12
1. Operating checklist •	•	12
2. Starting the generator set	•	16
3. Connect to electrical devices	•	19
4. Stopping the generator set	•	21
5. Parallel operation		21
IV. Maintenance •		22
1. Maintenance schedule •	•	23
2. Generator set maintenance	•	24
3. Engine maintenance •	•	24
V. Troubleshooting •		28
VI. Storage and transportation	•	29
VII. Specification	•	30
1. Wiring diagram •		30
2 Features and Technical Specs	•	32

I. OPERATOR SAFETY

1. 🗘 Safety Rules

Pay attention to this safety alert symbol. Obey all safety messages that followed by this symbol to avoid possible property damage, INJURY or **DEATH**.

Each safety message is preceded by a safety alert symbol and one of three words, **DANGER**, **WARNING**, or **CAUTION**.

⚠ DANGER

Indicates a hazardous situation which, if not strictly complied with, will result in substantial property damage, serious injury or **DEATH**.

♠WARNING

Indicates a hazardous situation which, if not strictly complied with, may result in property damage, serious injury or **DEATH**

!CAUTION

Indicates a hazardous situation which. if not strictly complied with, could result in property damage or injury.

Ⅲ WARNING

READ THIS MANUAL COMPLETELY BEFORE OPERATION.

DO NOT operate this generator set until you have read ALL safety, operation, and maintenance instructions listed in this manual.

Failure to follow the instructions may result in property damage, INJURY or DEATH.

The warnings and precautions discussed in this manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be possessed by the operator.

∕!\WARNING

This generator set is intended for residential consumer use only. Air cooled generator sets cannot be run full time.

DO NOT modify any part of the generator set and **NO** unsuitable usage is allowed.



TOXIC FUMES

The exhaust of the engine contains carbon monoxide, an odorless, colorless, poison gas. Using engine indoors

CAN KILL YOU!

NEVER use inside any building or any kind of enclosure, **EVEN IF** doors and windows are open. Place the engine in a well-ventilated area and carefully consider wind and air currents when positioning the engine.



!WARNING

KICKBACK

Rapid retraction of the starter cord will pull hand and arm towards the engine faster than you can let go.

Unintentional startup can result in entanglement, traumatic amputation or laceration. Broken bones, fractures, bruises or sprains.



! WARNING

FIRF

Operation of this engine may create sparks that can start fires around dry vegetation. This engine may not be

equipped with a spark arresting muffler. If the engine will be used around flammable materials, or on land covered with materials such as agricultural crops, forest, brush, grass, or other similar items, then an approved spark arrester must be installed. In some area, a spark arrester is required by law. Please contact local fire agencies for

Please contact local fire agencies for laws or regulations relating to fire prevention requirements.

WARNING

Lithium battery is maintenance free, if you have any question, please contact a local authorized dealer.



!WARNING

HOT SURFACE

heat. Severe burns can occur on contact. **DO NOT** touch engine while operating or just after stopping. Avoid contact with hot exhaust gases. Maintain at least three feet of clearance on all sides to ensure adequate cooling.

Combustible material can catch fire on

Running engine generators produce

contact. Maintain at least five feet of



FIRE OR EXPLOSION

Gasoline is highly flammable and extremely explosive. Fire or explosion can cause severe burns or death. Keep flammable items away while handling gasoline. Fill fuel tank outdoors and in a well-ventilated area with the engine stopped. Always wipe off spilled fuel and wait until the fuel has dried before starting the engine.

DO NOT operate the engine with known leaks in the fuel system. Use proper fuel storage and handling procedures.

DO NOT store fuel or other flammable materials nearby. Empty the fuel tank before storing or transporting this engine. Keep fire extinguisher handy and a be prepared if a fire starts.



! WARNING

Before each use, check for loose or damaged parts, signs of oil or fuel leaks, and any other condition that may affect proper operation. Repair or replace all damaged or defective parts immediately. Locate all operating controls and safety labels. Make sure all the safety instructions are in right and working condition.

Operate only on level surfaces.

DO NOT expose generator set to excessive moisture, dust, or dirt. Keep all safety guards in place and in proper working order at all times.

DO NOT allow any material to block the cooling slots.

DO NOT allow children or untrained persons to operate the generator set.

DO NOT run the generator set unattended. Turn off the generator set before leaving the area.



♠ DANGER

MOVING PARTS

Moving parts can cause severe injury. Keep hands and feet away.

DO NOT operate engine with covers, shrouds, or guards removed.

DO NOT wear loose-fitting clothing, dangling drawstrings or items that could become caught. Tie up long hair and remove jewelry. The moving parts may catch operator's hand, feet, hair or clothes that will cause traumatic amputation or broken bones, fracture.

NEVER place fingers, hands, or body near the engine when it is running.



ELECTRIC SHOCK

This generator set produces powerful voltage and the electricity **CAN KILL YOU**. This is generator set must be property connected to an appropriate ground to help prevent electric shock.

Failure to properly ground generator set can result in electrocution, especially if the generator set is equipped with a wheel kit. Consult an electrician for local grounding requirements.

Installation should be performed by a certified electrician.

Improper installation can result in electric shock and death. To reduce the risk of electric shock.

DO NOT use electrical cords that are worn, frayed, bare or otherwise damaged.

DO NOT touch bare wires or receptacles. **DO NOT** operate generator set in wet weather. Keep the generator set dry.

DO NOT handle generator set or electrical cords while standing in water, while barefoot, or while hands or feet are wet. Keep children or pets away from the generating set.

DO NOT hook up any generator set to a building electrical system without the proper use and installation of a transfer switch installed by a qualified electrician.

When using generator set for backup power, notify utility company.

Use approved transfer generator set to isolate generator set from electric utility.

Failure to isolate generator set from power utility can result in death or injury to electric utility workers due to backfeed of electrical energy.


II. FEATURES AND CONTROLS



- 1. Carrying handle
- 2. Fuel tank cap
- 3. Ventilation knob
- 4. Spark plug maintenance cover
- 5. Recoil starter

- 6. Control Panel
- **7.** Appearance cover
- 8. Muffler
- 9. Muffler blind window


Control Panel



- 1. Running indicator
- 2. Overload indicator
- 3. Oil alarm lamp
- 4. Choke lever
- 5. Parallel Connection
- 6. AC 120V Nema 5-20R **Duplex Receptacles**
- 7. USB Port
- 8. ON/RUN Switch
- 9. Grounding Nut
- **10.** Circuit Breaker
- 11. Eco Mode Switch
- 12. VFT Meter


Running indicator (green)

The running indicator lights up when generator set starts and has normal output.



Overload indicator (red)

When the overload indicator is on, it indicates that the generator set is overload and it may cause overheat of frequency converter, or increase of AC voltage. And then the AC protector works. It will stop the output of generating set to protect the electric equipment and the generator set itself. At this time, the running indicator (green) is off and the overload indicator (red) is on, but the engine is still in running state.




When the generator set has no output and the overload indicator is on, please take the following steps:

- 1. Lower the total power of the connected electric devices to the rated output range of generator set.
- 2. Check the air intake for impurities and check the control parts for abnormal situation. Handle immediately if necessary.
- 3. Press the reset button.

Oil alarm lamp (yellow)

When the oil level drops below the lower limit, the oil protection system will stop the engine automatically and oil alarming lamp will blink by pulling the recoil starter. The engine will not run until the oil has been filled to the proper level.




Note:

If engine flames out or fails to start, turn the two-in-one switch to "RUN" position and then pull the recoil starter. If the oil alarming lamp lights up, it shows lack of oil.

Please add appropriate oil and restart the engine.


Choke lever

Note: When cold start, please close (pull) the choke lever. When warm start, please open (push) the choke lever.



Energy-saving switch


When the energy-saving switch is in "ON" position, the energy saving equipment controls the engine rotate speed according to the connected loads. There will be good fuel consumption and low noise. When the energy-saving switch is in "OFF" position, the engine will always run in rated rotate speed no matter it is connected to the loads or not.



Note: Please set the energy-saving switch to "**OFF**" position when connect to air compressor, sinking pump etc., because these equipments need large starting current.

Grounding terminal


The grounding terminal is designed to prevent electric shock by connecting it to the grounding wire. The generator set must be properly grounded before operation.



ON and RUN switch

(engine stop & fuel switch)


When the switch is in "**ON**" position, it indicates that the engine is turned ON and fuel switch are in off state.



When the switch is in "**RUN**" position, it indicates that the engine stop switch and fuel switch are in on state.

Circuit breaker/Reset button


The reset button is used to restore output if an overload occurs. To restore output, reduce the loads and press the reset button.



The circuit breaker protects the generator set against electrical overloads.


Parallel kit terminal

It is used for parallel operation with another inverter (parallel kit sold separately).




Fuel tank cap

Remove the fuel tank cap by rotating it anticlockwise.



Ventilation knob



The fuel tank cap is equipped with the ventilation knob to prevent leakage of fuel. The ventilation knob must in "ON" position when operating generator set. Because this makes the fuel be injected to the carburetor and drive the engine. To avoid fuel leakage, turn it in "OFF" position when carrying or not use the generator set.

III. OPERATING

1. Operating checklist

Operating Location

Only use **OUTSIDE** and place the generator set in a well-ventilated area. Only operate the generator set on a flat, level surface and in a clean, dry operating environment.

Allow two feet clearance on all side of the generator set while operating it outdoors.

Operate in specified area, if any problem on applicable occasion, please consult the authorized local authority. In some areas, generator set must be registered with the local utility. Generator set used to construction sites may be subject to additional rules and regulations.



The exhaust of the generator set contains carbon monoxide.

Using engine indoors **CAN KILL YOU! NEVER** use inside any building or any kind of enclosure, **EVEN IF** doors and windows are open. Place the generator set in a well-ventilated and clean area. Note the wind direction and air current when placing the engine.

High altitude

This generator set may require a high altitude carburetor kit to ensure correct operation at high altitudes. Consult the authorized local dealer for high altitude kit information if you always operate your engine at altitudes above 5,000 feet (1,500 meters).

!\CAUTION

Even with carburetor modification, generator set horsepower will decrease about 3.5% for each 1,000 feet (300 meters) increase in altitude.

The effect of altitude on horsepower will be greater than this if no carburetor modification is made.

! CAUTION

Operation the engine at altitude below 5,000 feet (1,500 meters) with modified carburetor may cause the generator set to overheat and result in serious engine damage. Please restore factory specifications of the carburetor at the dealer when using the engine in a low altitude area.

2. Operating Condition

Check for loose or damaged parts, signs of oil or fuel leaks, and any other condition that may affect proper operation. Repair or replace all damaged or defective parts immediately.


/!\WARNING

Failing to correct problem(s) before operation could result in property damage, serious injury or **DEATH**.


Remove any excessive dirt or debris, especially around the muffler and recoil starter. **DO NOT** move or tip the generating set during operation. Use generator set only for intended uses. If you have questions about intended use, ask your local dealer.

3. Engine oil check

Place the engine on a level surface with engine stopped. Check the engine oil level. Remove the oil maintenance cover.





Remove the dipstick and wipe it clean.



Reinstall dipstick into hole; rest on oil fill neck. **DO NOT** thread cap into hole. Remove the dipstick again and check oil level. Level should be between the upper and lower limit.

Fill to the upper limit of the dipstick with the recommended oil if the oil level is too low.





Reinstall and fully tighten the dipstick.
Refer to **add oil** instruction in **MAINTENANCE** section for more information.

Oil capacity (rated):
See Parameters

WARNING

Oil is a major factor affecting performance and service life. Use 4-stroke automotive detergent oil recommended in the **MAINTENANCE** section of this manual.

!\CAUTION

Operate generator set only on leveled surfaces. The engine is equipped with a low oil sensor (applicable types) that will automatic stop the engine when the oil level falls below the safe limit. To avoid the inconvenience of an unexpected shutdown. Fill to the upper limit and check the oil level regularly.

WARNING

This engine is not filled with oil before send out to the factory. Any attempt to crank or start the engine before it has been properly filled with the recommended type and amount of oil may result in engine damage and void your warranty.

4. Generator set fuel check

With the engine stopped, check the fuel level. Refill the fuel tank if necessary.

Use clean, fresh, regular unleaded gasoline.

DO NOT mix oil with gasoline. Always wipe up any spilled fuel.

(!\CAUTION

Pressure can build up in the fuel tank. Allow the generator set to cool for at least two minutes before removing fuel cap. Loosen the fuel cap slowly to relieve any pressure in the tank

Be sure not to fill above the upper limit mark. Always allow room for fuel expansion.

Fuel capacity (rated): See parameters.





! DANGER

FIRE OR EXPLOSION

Gasoline is highly flammable and extremely explosive.

Keep flammable items away while handling gasoline.

Fill fuel lank outdoors and in a well-ventilated area with the generator set stopped. Always wipe off spilled fuel and wait until the fuel has dried before starting the generator set.

DO NOT operate the generator set with known leaks in the fuel system. Regularly check if there is any leak on fuel system.

Use proper fuel storage and handling procedures. **DO NOT** store fuel or other flammable materials nearby.

Keep fire extinguisher handy and be prepared if a fire starts.

/!\DANGER

Do not fill the fuel tank above the upper limit. Over fill will result in engine die or damage the carbon canister (if equipped) and void your warranty.

NEVER use engine or carburetor cleaner products in the fuel tank or permanent damage may occur. It is important to prevent gum deposits from forming in essential fuel system parts. Such as the carburetor, fuel filter, fuel hose or tank during storage. Also, experience indicates that alcohol-blended fuels (called gasohol, ethanol or methanol) can attract moisture, which leads to separation and formation of acids during storage. Acidic fuel can damage the fuel system of the generator set while in storage. Be sure to review the instructions given in "Storage" section.

Gasoline/Alcohol blends: up to 10% alcohol, 90% unleaded gasoline by volume is approved as a fuel.
Other gasoline/alcohol blends are not approved. Effects of old, stale or contaminated fuel are not warrantable.

!CAUTION

To minimize gum deposits in your fuel system and to insure easy starting, do not use gasoline left over from the previous season.


∕!\CAUTION

Allow the generator set to cool for at least two minutes before removing fuel cap when adding fuel.

Loosen the fuel cap slowly to relieve any pressure in the tank.

5. Internal battery grounding (Applicable types)

Remove the appearance cover plate. Use the nut of M6 to connect the battery grounding wire with cylinder head cover to make the ground connection of internal battery.



6. Electrical devices

Disconnect all electrical devices from the generator set and switch off the AC circuit breaker before start the engine. The generator set may be hard to start with electrical devices connected. The power of connected electrical devices cannot limit the generator set max power, specific power see parameter sheet for reference.

7. Generator set grounding

The generator set must be properly connected to an appropriate ground. It helps prevent electrical shock if a ground fault condition exists in the generator set or in connected electrical devices, especially when the unit is equipped with a wheel kit. Proper grounding also helps dissipate static electricity, which often builds up in ungrounded devices.



! DANGER

Electrical Shock


Failure to properly ground the generator set can result in electric shock.

A ground terminal on the frame of the generator has been provided on the generator end. For remote grounding, connect a length of heavy gauge (4 mm²) copper wire between the generator ground terminal and a copper rod driven into the ground.


Local electrical codes may also require proper grounding of the unit. We strongly recommend that you consult with a qualified electrician for grounding requirements in your area.

2. Starting the generator set

- 1. Perform operating checklist and remove all loads.
- 2. Turn the ventilation knob to "**ON**" position when engine is running to make sure the fuel flowing.




3. Turn the ON/RUN switch to the "RUN" position.



4. Turn the energy saving switch to the "**ON**" position.

(**Note:** Please set the energy-saving switch to "**OFF**" position when it needs large starting current.)



(Suitable for hand recoil starting) Pull out the choke lever to close the choke valve.



ACAUTION

Choke position for starting may vary depending upon temperature and other factors. If re-starting a warm engine, there's no need to pull out the choke lever.

6. Manual start Hand recoil starting:

ACAUTION

Check starter cord conditions before operating. Have it replaced immediately by local authorized dealer if cord is frayed.

When starting engine, grasp the recoil starter handle and pull slowly until resistance is felt.

Then pull rapidly to avoid kickback. When pulling the recoil starter, firmly grasp the carrying handle to avoid tumble of generator set.





!WARNING

KICKBACK

Rapid retraction of the starter cord will pull hand and arm towards the engine faster than you can let go.

Unintentional startup can result in entanglement, traumatic amputation or laceration. Broken bones, fractures, bruises or sprains.

If the starter cannot drive the engine to rotate, turn off the starter immediately. Do not attempt to start the engine again before finding the causes of the fault. Prohibit the unauthorized change of other battery for re-start.

/ WARNING

The engine starts time cannot exceed 15 minutes. If the engine fails to start, allow the starting motor to cool for one minute before restart.

Failure to operate according to this rule will damage the starting motor.

ACAUTION

If the engine fails to start after attempt for 3 times or flames out after starting, inspect and ensure that the generator set is placed in horizontal surface and enough engine oil is injected. If engine is equipped with an engine oil alarm, it is possible to prevent engine start when the engine oil in the crankcase is lower than the minimum level. During running-in, routinely inspect the engine oil. See maintenance section for recommended maintenance period.

After the engine starts successfully, and the temperature has been increased, push the choke lever to open the choke valve. If the engine runs unstably (shaking exists), push the choke lever to the **HALF** open position. Then push it to the **FULL** open position after engine runs stably.




ACAUTION

If the engine is in warm state, open the choke lever when restarting the engine.


!WARNING

When the starting battery of the generator set is low in voltage and pull starting the generator does not work, please make sure the fuel tap is in the on position. Please try and operate the choke lever according to the below diagram. This will add choke to the engine to help the generator engine to start when the battery is low in volts and not being able to move the choke automatically.



NOTE: Sometimes the generator can take a few attempts to start in cold weather. If machine does not start in the first 10 seconds, wait for 30 seconds before attempting again. If the motor turns a little then stops when you press the Start key, it may indicate a low battery. Charge the battery before operation or start by recoil start.

7. After all the operations, the engine can be normally loaded.



DANGER

It is prohibited to start or close the generator set when the output terminal of generator set is connected to an electric device and the electric device is in "**ON**" state.

3. Connect to electrical devices

Note:

- Inspect power cord for damage before using. There is a hazard of electrical shock from crushing, cutting or heat damage.
- Make sure that the generator set has been properly grounded. If the electric devices require grounding, the generator set must ground.
- 3. Allow the engine to stabilize and warm up for a few minutes after starting.

- 4. Make sure that the electric devices are in "**OFF**" position.
- 5. Connect and start the electric devices.
- 6. Turn off all electric devices & disconnect them from the generator set.
- 7. If the generator set supplies for several loads or electric devices, start the smallest one first and the largest one last.

!\CAUTION

If connected devices overheat, turn them off and disconnect them from generator set.



ADANGER

Electrical Shock

To reduce the risk of electrical shock. **DO NOT** use electrical cords that are worn, frayed, bare or otherwise damaged.

DO NOT touch bare wires or receptacles. **DO NOT** handle generator or electrical cords while standing in water, or barefoot, or while hands or feet are wet.

Loading capacity

!WARNING

DO NOT overload the generator set.

Exceeding the generator set's capacity can damage the generator set and/or electric devices connected to it.

You must make sure your generator set can supply enough rated (running) and (starting) watts for the electrical devices at the same time.

Follow these simple steps to calculate the running and starting watts necessary for your purposes.

- **a.** Count the electrical devices you will power at the same time.
- b. The amount of power you need to run with the devices is the total rated (running) watts of these items.
- c. Starting power is the power needed shortly when electric devices start.

 Since not all devices start at the same time, starting power can be estimated by the maximum power of all devices plus the total power counted in step "b".

!WARNING


It is necessary to equip with circuit protector or switch to isolate the generator set from the electric utility when the generator set is mainly used for backup. Failure to isolate the generator set from the power utility may result in injury or death to electric utility workers and damage to the generator set due to back feed of electrical energy.

Wattage Reference Chart

Electric equipment		Rate power (w)	Starting power (W)	
Appliances	Tablet computer 27"	80	100	
	Energy saving lamb	5-50	5-50	
	Electric cooker	1000	1000	
	Computer	250	250	
	Electric fan	50	100	
	Washing machine	250	500	
	Refrigerator	50	300	
	Air-conditioner	1600	3200	
	Electric hammer	1000	1500	
Electric tooling	Impact Hammer	3000	6000	
	Water pump	2200	5000	
	Electric welding machine	5000	7500	
	Air compressor	5000	10000	

4. Stopping the generator set

Remove the connectors of all electric equipment from the generator set panel.




!WARNING


NEVER stop the engine with electrical devices connected and running.

Note: If the generator will not be in service for over 2 weeks, please turn the knob to "**OFF**" position, or the battery will be out of power and the generator will not start.

Turn the energy saving switch to "ON" position.



- 4. Allow the generator set run at no load for a few minutes to stabilize internal temperatures of the engine and generator set.
- Turn the ON/RUN switch to "ON" position.



5. Parallel operation (If applicable)Make sure that the generator set is

in a good running state before connecting it to other generator sets. The total power of electric devices should not exceed rated power of generator set. When electric motor starts, the overload indicator (red) will light up and normally it will stop within 4 seconds. If it cannot stop, please consult your local dealer. During parallel operation, energy-saving switch of generator set should be in the same position.

- 1. Connect one generator set to other generator set(s) in parallel. Use the parallel kit to make the parallel connection (the parallel kit needs to be purchased separately).
- **2.** Start the engine in proper order and make sure that the running indicator (green) is normal.
- **3.** Connect the plug of electric devices to the AC receptacle of parallel kit.
- **4.** Run the electric devices.

!\CAUTION

When overload too much, overload indicator (red) blinks continuously, and the generator set may be damaged. When overload a little, overload indicator (red) lights up continuously, it may shorten the service life of generator set. When continuously operating the generator set, power cannot exceed the rated power of generator set. The total power of electric devices cannot exceed the rated power of generator set.

The manufacturers of electric devices or tools always list the rated power of similar models or serial number.

IV. MAINTENANCE

It is the operator's responsibility to complete all scheduled maintenance in a timely manner. Correct any issue before operating the generator set. Always follow the inspection and maintenance recommendations and schedules in this manual.

!WARNING

Improper maintenance or failure to correct a problem before operation can cause a malfunction and result in property damage, serious injury or **DEATH**. Improper maintenance will void your warranty.



!DANGER

Accidental starts can cause severe injury or death. Remove the spark plug cap and ground generator set before performing any service.

!CAUTION

The filter element may contain PAHs.
PAHs are harmful for your health.
Please wear gloves for protection during air filter maintenance.

1. Maintenance Schedule

Stop the generator set before serving, disconnect all electric devices and battery (if equipped), and cool down the generator set completely. Serve the generator set in a clean, dry and flat area, so that no accident would happen during the serving. Please make the wheel in brake state to stop accidental movement of generator set. Follow the service intervals indicated in the chart below. Service your generator set more frequently when operating in adverse conditions. Contact your local authorized service dealer for your generator set or engine maintenance needs.

		Each time before use	The first month or 10 hours	Every three months or 50 hours note2	Every six months or 100 hours	Every year or 300 hours ^{note2}
Engine oil	Inspection	√				
	Replacement		V		√	
Air filter	Inspection	√				
	Cleaning			√ note3		
Spark plug	Inspection and adjustment				$\sqrt{}$	
	Replacement					√
Spark Extinguisher ^{note1}	Cleaning				√	
Idle speed	Inspection and adjustment					√note4
Valve clearance	Inspection and adjustment					√note4
Carbon canister ^{note1}	Inspection	Every two years ^{note4}				
Low permeability oil tube note1	Inspection	E		Every two years ^{note4}		
Oil tube	Inspection	Every two years ^{note4}				

NOTE:

- Note 1: Applicable types (if available).
- Note 2: Before each season and after then (whichever comes first).
- Note 3: Service more frequently under severe, dusty, dirty conditions.
- **Note 4:** To be performed by knowledgeable, experienced owners or the authorized dealer.

2. Generator set maintenance

Use a damp cloth to clean exterior surfaces of the generator set. Use a sort brush to clean the dirt and oil. Use an compressed air (25 PSI) to clear dirt and debris from the generator set. Inspect all air vents and cooling slots to ensure that they are clean and unobstructed.

WARNING

DO NOT use water to clean the generator set. Water can enter the generator set through the cooling slots and damage the generator set windings.

/ WARNING

DO NOT modify the generator set in any way.

DO NOT tamper with modified the speed regulator. Generator set supplies correct rated frequency and voltage when running at factory set.


Tampering with modify the factory set governor will void your warranty.

3. Engine Maintenance

Engine oil

Only use four-stroke engine oil of SJ, SL or equivalent level which are in accordance with or higher than API standard.


Check the API label on oil bottle or other container, and make sure the "SJ, SL" or equivalent level letter is in the label. SAE 10W-30 is recommended for general, all-temperature use. Other viscosities shown in the chart may be used when the average temperature in your area is within the indicated range.




Oil capacity (rated): See parameters

Add oil

- a. Place the engine on a level Surface.
- b. Remove the dipstick and wipe it clean.



c. Add recommended oil to the upper limit.



- d. Fully tighten the dipstick.
- e. Dispose of used oil at an approved waste management facility.

WARNING

Oil level check

Reinstall dipstick into hole; rest on oil fill neck. **DO NOT** thread cap into hole.


 f. Properly dispose of any used oil at an approved waste management facility.

Change Oil


WARNING

Change oil when the engine is warm from operation.

- a. Place the machine on a level surface which is 300mm higher than the ground.
- b. Remove the oil maintenance cover.



- c. Place the waste oil box on the ground.
- d. Remove the oil dipstick, and tilt the machine to pour the oil.



e. Add recommended oil to the upper limit.




- f. Fully tighten the dipstick.
- g. Properly dispose of any used oil at an approved waste management facility.
- h. Reinstall the oil maintenance cover.

! WARNING

The engine is not filled with oil at the factory. Any operation before it has been properly filled with the recommended type and amount of oil may result in engine damage and void your warranty.

Air filter

- a. Remove the appearance cover.
- b. Loosen the filter fix clamp and remove the cover of the air filter.
- c. Remove the foam filter element.
- d. Wash in liquid detergent and warm water.
- e. Squeeze thoroughly dry in a clean cloth.
- f. Saturate in clean engine oil.
- g. Squeeze in a clean absorbent cloth to remove all excess oil.
- h. Assemble the filter element onto the filter unit.
- i. Assemble the filter fix clamp.
- j. Reinstall the appearance cover.




WARNING

DO NOT run the engine without the air filter, or serious danger can result.

Spark plug

- a. Clean any dirt from the spark
- b. Remove the spark plug cap.
- c. Using socket wrench to loose and remove the spark plug.
- d. Inspect the spark plug and spark plug washer, if it was broken or worn, replace with a new one. Clean the spark plug with wire brush if reuse it.
- e. Check spark plug gap. Carefully bend side electrode to adjust the gap if necessary.

Spark plug gap: 0.6mm-0.8mm



- f. Carefully thread the plug into the engine by hand.
- g. After the spark plug is seated, use spark plug wrench to tighten the plug.

Spark Plug Tighten Torque: 15-20 N.m


h. Attach the spark cap to the plug and connect the spark plug wire to the plug.

WARNING

Only use recommended spark plug or equivalent. **DO NOT** use spark plugs that have improper heat range.

Spark Arrester (Applicable types)

- a. Allow the generator set to cool completely before servicing the spark arrester.
- b. Remove the muffler blind window first.
- c. Remove the spark arrester screen.
- d. Carefully remove the carbon deposits from the spark arrester screen with a wire brush.
- e. Replace the spark arrester if it is damaged.
- f. Reinstall the spark arrester in the muffler and reinstall the muffler blind window.



Clean carbon deposit

V. TROUBLESHOOTING

Failure	Trouble	Solution		
	Two-in-one switch is in "OFF" position.	Turn two-in-one switch to the "RUN" position.		
Generator set fails to start	Lack of fuel.	Fill fuel tank per instructions in this manual.		
	Lack of engine oil.	Check oil level. This engine is equipped with a low oil sensor. The engine cannot be started unless the oil level is above the prescribed lower limit.		
	No ignition.	Remove the spark plug cap. Clean any dirt around the plug base, and then remove the spark plug. Install the spark plug in the plug cap. Turn the two-in-one switch to "RUN" position. Grounding the electrode to any engine ground, pull the recoil starter to see if sparks jump across the gap. If there is no spark, replace the plug.		
		Reinstall the plug and start engine according to instructions in this manual.		
		Consult Customer Service if necessary.		
	Spark plug is splashed by fuel	Remove the spark plug and wipe the fuel.		
	The generator set flames out after running for a	Turn the ventilation knob on the fuel tank cap to "ON" position;		
	certain time.	Check the fuel and oil level. Add them if necessary.		
	Breaker trip	Reset circuit breakers.		
Generator set has no output	Inadequate cord sets or extension cords.	Check cord sets or extension cords capabilities in section controls; cable size in this manual.		
		Consult Customer Service if necessary.		

VI. STORAGE AND TRANSPORTATION

Storage

The generator set should be started at least once every 2 weeks and allowed to run for at least 20 minutes. Follow the instructions below for longer term storage if the generator set will be out of service for 2 months or more.





!\DANGER

Fire or explosion

Gasoline is highly flammable and extremely explosive. Empty the fuel tank and shut off fuel valve before storing or transporting this generator set.

- 1. Allow the generator set to cool completely before storage.
- 2. Clean the generator set according to instructions in Maintenance section.
- Drain all fuel completely from the fuel tank, fuel hose and carburetor to prevent gum from forming.
- 4. Close the fuel switch to cut down fuel supply.
- Remove the appearance cover plate. Unscrew the oil dipstick and slightly tilt the whole set to pour out the oil.
- 6. Remove the spark plug and pour about 15ml. of oil into the cylinder. Pull the recoil starter slightly to distribute the oil and lubricate the cylinder. And then attach the spark plug.

7. Store the unit in a clean, dry area out of direct sunlight.

Transportation

To prevent fuel spillage when transporting or during temporary storage, the generator set should be secured upright in its normal operating position, with the engine switch OFF. The ON/RUN switch should be turned OFF.

!WARNING

When transporting:

Do not overfill the tank. Do not operate the generator set while it is on vehicle. Take the generator set off the vehicle and use it in a well-ventilated place.


Avoid a place exposed to direct sunlight when putting the generator set on a vehicle. If the generator set is left in an enclosed vehicle for many hours, high temperature inside the vehicle could cause fuel to vaporize resulting in a possible explosion.

Do not drive on a rough road for an extended period with the generator set on board. If you must transport the generating set on a rough road, drain the fuel from the generator set beforehand.


VII. SPECIFICATION

1. Wiring diagram

RECOIL START



ELECTRIC START



NOTE:

Because of the difference of generator, the wiring diagram is only for reference.

VII. SPECIFICATION

Features:

- USB Port and Multiple Outlets
- Portable and Compact Form with Carrying Handle
- Low Idle Technology for Extended Run Time
- Built-in Fuel Gauge
- EPA III and CARB Compliant
- Quiet Operation
- Lightweight Design
- Clean Energy and Double the Power
- Versatile Panel
- Automatically Adjust its Fuel Consumption
- Saves Money by Preventing Unnecessary Gasoline Usage
- Safe for Electronics such as TV, Tablets, Laptops and Other Sensitive Equipment
- Great for Campgrounds, Construction Sites, Tailgates, and Power Outages

What's in the Box:

- AC 120V NEMA 5-20R Duplex Receptacles
- (1) 5V USB Port
- Parallel Function
- Reset Button
- Eco-mode Switch
- Circuit Breaker
- Grounding Nut
- Indicator Lights
- COn/Off Switch
- Choke Lever
- V-F-T Display
- Screw Driver
- Spark Plug Socket
- Funnel
- Grounding Wire





This product can expose you to a chemical or group of chemicals, which may include "Carbon monoxide and engine exhaust" which is known in the state of California to cause cancer, birth defects, or other reproductive harm. WARNING: For more info, go to https://www.p65warnings.ca.gov/.

Engine Technical Specs:

- Engine Model: 148F
- Engine Displacement (cc): 79
- Engine Type: 4 Stroke, OHV, Single Cylinder with Forced Air Cooling System
- Engine Speed: 4800 RPM
- Half-Load Run Time: 5-7 Hours
- Spark Plug Type: Torch E5T (NGK BP5H)
- Spark Plug Gap: 0.6 mm 0.8 mm (0.02 in.-0.03 in.)

• Spark Plug Torque: 11.1-14.7 ft.-lbs. (15-20 Nm)

Technical Specs:

• Surge Wattage: 2100W

• Running Wattage: 1900W

• Noise Levels: 58 dB

• Fuel Tank Size: 1 Gallon

• Life Span: 500h

- Frequency Response(Hz): 60Hz
- Rated Power (KW): 1.9
- Max Power (KW): 2.1
- Voltage (V): AC 120V NEMA 5-20R Duplex Receptacles, (1) 5V USB Port
- Max Fuel Tank Size (L): 4L
- Running Time At 50% Loading(H): 5.7
- Starting System: Recoil
- Alternator Material: Permanent Magnet
- THD(%): ≤3%
- Oil Capacity (L): 0.5
- Construction Material: Engineered ABS, Aluminum
- Grounding Wire Length: 4.92 ft.
- USB Port 5V, 2.1A+1A
- Rated Amperage: AC:15.8A, 2.1A/1A (USB)
- Product Dimension (L x W x H): 17.3" x 11.5" x 17.7" -inches





Questions? Issues?

We are here to help!
Phone: (1) 718-535-1800
Email: support@pyleusa.com