



Portable Bluetooth Wireless BoomBox Stereo System, Built-in Rechargeable Battery, Aux (3.5mm) Input

USER MANUAL



PBMSPG11

Pyle BT Portable Speaker

PBMSPG11 USER GUIDE



For correctly operating, please read this manual carefully before using. Any content revise of the manual won't declare again, and we are no responsible for consequence caused by fault or oversight of this manual

FEATURES:


1. 2.1 outdoor Passive Bluetooth Speaker with 3 inch subwoofer
2. Output very clear sound and heavy bass, dynamic sound effect
3. With A2DP Bluetooth, wireless stream music from any Bluetooth-enabled device such as your mobile phone, notebook, iPhone or iPad
4. Secure simple pairing for user-friendly operating
5. 10 meters operating range
6. With Line-in function, suitable for PC, MID, TV and other audio device.
7. Built-in lithium rechargeable battery 1500mAh
8. With strap, easy to take out.
9. Digital Sound Amplifier
10. Aux (3.5mm) Input Jack
11. Side Panel Button Control Center
12. Full Range Stereo Sound Reproduction
13. Ported Enclosure Design for Impressive Bass Response

What's in the Box:

Wireless Tube Speaker
USB Charging Cable
Audio Connection Cable
Detachable Carry Strap

APPEARANCE AND BUTTONS:

Instruction baby



- 1.Backward
- 3.Forward
- 5.Aux-in jack

- 2.Play/Pause
- 4.On/Off button
- 6.Charging jack

Bluetooth:

1. Turn the power button to “ON”, The LED light turn blue and twinkle quickly and beep twice.
2. Activate *Bluetooth* of mobile phone and search for device name “BT speaker” then connect it. The blue LED light twinkle slowly and beep third times once connected successful.
3. Play the music from your mobile phone and enjoy.
4. Press LAST or NEXT button on the devices or on Mobile phones to select songs you like.
5. Press Play/pause button on the devices or on Mobile phones to play/stop the music
6. Use the Bluetooth device to adjust volume up and down. Or long press to fast forward or backward to adjust volume up and down.

AUX-IN:

For other compatible music devices or your MP3/MP4 players, use the supplied audio line cable to connect from the device's "Line Out" to the "Aux In" of this device. Then press the "MODE" button to switch to AUX-IN state. Enjoy...

When using an external device, all functions will be controlled by the external device except the "Play/pause" button.

Remarks:

1. Press the MODE button to switch the different modes, the order is Bluetooth, and AUX-IN.
2. Turn the power button to "off" to cut off the power supply while without use.

How to charge:

1. Power off the unit, put the provided charge cable into the charge slot of unit, connect the other end to PC or other charger with 5V output (Not included), the red charging indicator keep lighting.
2. Charge time should be 3-5 hours. When charging full, the indicator light will switch off.
3. In order to prolong the life of battery, please do not charge more than 8 hours.



VISIT US ONLINE:

Have a question?

Need service or repair?

Want to leave a comment?

PyleUSA.com/ContactUs

PYLE