

PKWNARA50
ELECTRONIC WINE &
SPIRIT AERATOR



CONTENTS

- Clean Before First Use 1.
- 2. Specifications
- User Instructions 3.
- Cautions 4. Clean and Store

We suggest that you run clean water through the Aerator before first use. The product is designed to seal on a standard wine bottle mouth opening and will only push water through the tube and spout if used in a sealed state.

SPECIFICATIONS

	Φ60*162.5 mm
SIZE	(Tube and Spout not included)
TUBE LENGTH	95-180mm
WEIGHT	83g (Batteries not included)
POWER SOURCE	2 X AAA Battery




Mixes Wine & Air to provide a purer wine taste & experience!







USER INSTRUCTIONS

Dispense Switch



Remove the Top Cover from the Electronic Body Assembly through turning the cover to the right (counter clockwise) and pull the cover up and off the Electronic Body Assembly to expose the battery compartment





- Do not use detergents to clean the Tube.
- Remove the battery if haven't used in a long time.
- Be sure to remove the Tube Part from Aerator before cleaning.
- This product is not a toy and contains small parts. Not suitable for children under 5 years of age.

6

CLEAN AND STORE

- 1. After use, immediately clean and dry.
- 2. Wipe it clean and dry.
- Add a little lemon juice or vinegar if you want to improve the cleaning effect

Remove the Tube to the spout under the Electronic Body Assembly by turning the tube to the right (counterclockwise) and pull the tube down

Connect the Tube to the spout under the Electronic Body Assembly by turning the tube to the left (clockwise)





Have a question?

Need service or repair?

Want to leave a comment?

PyleUSA.com/ContactUs

DYLF