

# **USER'S MANUAL**

---

## **UNIVERSAL MOUNT TFT LCD FLAT PANEL MONITOR**




[www.pyleaudio.com](http://www.pyleaudio.com)

**PLVW17iW 17"**


**PLVW19iW 19"**

Please read this Manual thoroughly before using this product and keep it well for future reference.

## Connection



## Remote Control Function Description



1. Power Switch
2. Video Selection
3. Analog “-”
4. Menu
5. Analog “+”
6. Mode Selection

## Specifications

- TFT LCD Screen Wall Mount
- PAL/NTSC Auto Color System
- 16:9 Screen Aspect Ratio
- 1440x900 High Resolution
- 400:1 Contrast Ratio
- Wireless Remote Control
- Brightness: 350 cd/m<sup>2</sup>
- Viewing Angle: 40°Up / 70°Down / Left & Right 70°
- Video Input: RCA & VGA & VESA
- Power Supply: DC 12V
- Dimensions: (Screen) 18.3"W X 11.22"H x 1.10" D
- Weight: 2.3 kg

IN WALL/WALL MOUNTABLE FOR HOME /  
MOBILE / MARINE (BRACKETS INCLUDED)

## Trouble Shooting

Phenomenon	Causes
can not start-up	1. check if the power cable is connected correctly 2. use remote control to adjust the unit, check if the battery in the remote control is installed correctly
no picture:	1. check video connection if it does work 2. check the video selection 3. check the Vertical Scanning Frequency of VGA input if it is ok
picture showing abnormally:	1. check video selection 2. check power
remote control can not work:	1. check the battery in the remote control if it is workable 2. check the battery if it is fixed well