

User manual for mini shotgun microphone PMKSF32

Description:

PMKSF32 mini shotgun microphone is designed intelligently and compact, fits perfectly because of its light weight and small dimensions. It attaches easily to your camera or video . The line and gradient patterns eliminate unwanted background noise when you make recordings. The shotgun is the ideal tool for video/camera recording, weddings, sporting events, interviews, pod-casts, speeches or professional film/video production. Also it can be used in any situation where you want to listen to what's in the shot, not what's at the side or out of view.

Features:

- All Metal Construction
- Compact, lightweight body
- Condenser microphone
- Low noise circuitry
- Low handling noise
- Dark gray matt
- Ballpoint pen size
- Integrated shock mounting(Rubber bands holder)
- Integrated foam windshield

Specifications:

- Element: Back Electret Condenser
- Polar Pattern: Line and gradient
- Frequency Response: 50Hz-18KHz
- S/N Ratio.....70dB
- Sensitivity: -42dB± 3dB
- Output Impedance: $1K \Omega \pm 30\%$
- Max.Input SPL: 130dB
- Power Supply: 2*377button cells (SR626SW)
- Dimension: . $\Phi 9.5mm*140mm$
- Weight: g
- Connector: 3.5mm connector plugs into video/camera
- Accessories:

Wind shields-shock mount Attaching the microphone to the shock mount

How to use:

Push the mini shotgun mic into the hole in the center of the crossed rubber bands in the hoops of the shock mount. The microphone should be pushed in so that the rear rubber bands sit in the middle of. The raised section of the microphone, which is the battery compartment.

Battery replacement

The battery, when used under normal operating conditions should have over 100 hours of continuous use; the battery is only used when the microphone is plugged into the camera or recording device.

The replacement batteries are two 1.5Volt SR626SW(D377B) which can be purchased from any camera store. The positive side (+) of the battery should face up when looking into the battery housing with the shotgun section detached from the housing.

Note: Please take out batteries when not in use.



Pyle Audion
1600 63rd St.
Brooklyn, NY 11204
www.pyleaudio.com