

**PYLE**  
PyleUSA.com



*PPHP108WMU*

## Wireless & Portable BT Loudspeaker

PA Speaker System, FM Stereo Radio, Built-in Rechargeable Battery,  
USB/SD Readers, Includes Handheld Microphone, 1000 Watt, 10" Subwoofer

**USER MANUAL**

## WARNING!

**CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK,  
DO NOT REMOVE THE COVER OF THIS UNIT.**

**THERE ARE NO USER - SERVICEABLE PARTS INSIDE.  
REFER ALL SERVICING TO A QUALIFIED TECHNICIAN.**



The lighting flash with arrow head symbol within an equilateral triangle is intended to alert the user to the presence of “dangerous” voltage within the product’s enclosure that may be of sufficient magnitude to constitute a risk of Electric shock to humans. Users should exhibit extra safety when this symbol appears in this instruction manual and follow all precautions as they are stated.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) in instructions in this manual.

### **SAFETY INSTRUCTION**

1. Please read the user manual carefully before use and retain for future reference.
2. The power supply must match the demand of the device with reliable ground wire.
3. All covering signal should be complied with the demand of device.
4. The device should be located far away from high temperature, moisture and powerful electromagnetic field.
5. Max operating temperature is 113°F.
6. No naked flame sources, such as lighted candles, shall be placed on the product.
7. **Clean only with dry cloth** – The appliance should be cleaned only as recommended by the manufacturer.
8. When not in use, unplug the unit from the mains.
9. **To establish a safe level:**
  - Start your volume control at a low setting.
  - Slowly increase the sound until you can hear it comfortably and clearly, and without distortion.
10. Only use suitable means of transportation if you want to move the speaker.

### **Note:**

- Once the WIRELESS BT devices are paired, there is no need to pair them again.
- If the speaker is connected via BT device but does not play with sound, please turn off nearby devices and only leave one device to re-connect with the speaker.
- When inserting the USB/SD Card, make sure the direction you selected is correct. Never insert violently to avoid damaging the USB/SD Card or the unit. If it doesn't work, please check if the direction is correct.
- Turn off and pull out the USB/SD before turning off the speaker.

# WARNING





RECHARGEABLE BATTERY INSIDE  
CHARGE THE BATTERY EVERY 30 DAYS EVEN IF NOT USE



CHARGE THE BATTERY  
STOP CHARGING IMMEDIATELY

## CONTROLS AND CONNECTIONS



1. LCD screen
2. Mp3 control
  - MODE:** USB/SD/BT/FM/LINE(AUX) converter
  - ▶▶ : Play / Pause
  - SCAN:** Long press to auto search under FM radio
  - ▶▶ : Press and hold for 3 seconds to enter the folder option function mode (press the previous/next songs button to choose the folder)
  - ↻ : Repeat one / Repeat all / Random
  - ◀▶ : PRE/NEXT under FM mode  
Press and hold to search lower/higher station manually
  -  : Short press to tune to saved station
  - ◀◀ : Previous Song  
Press and hold for fast rewind
  - ▶▶ : Next Song  
Press and hold for fast forward
3. USB input
4. SD Card input
5. IR Remote control receiver
6. MIC level control
7. Echo control
8. Bass control for low frequencies
9. 6.35 microphone line input
10. RCA MIX output
11. RCA LINE input
12. 6.35 mic2 input
13. Aux input
14. MP3 level control
15. Master volume
16. FM antenna
17. A channel volume control  
Wireless microphone A channel indicator
18. B channel volume control  
Wireless microphone B channel indicator
19. Wireless power indicator  
Wireless mic power switch
20. Main power switch
21. Battery charge switch
22. DC power interface
23. Charge indicator  
Battery low indicator  
Battery full indicator
24. IEC main inlet

### **Wireless BT Connectivity:**

- Instantly Stream Music from Your Wireless BT Devices
- Works with All Your Favorite Wireless BT Devices (iPhone, Android, Smartphone, iPad, Tablet, PC, etc.)
- Wireless BT Version: 4.0
- Wireless Range: 100'+ Feet
- Wireless BT Network Name: 'Pyle'

### **What's in the Box:**

- PA Speaker
- Wireless Handheld Microphone
- Headset Microphone
- Beltpack Transmitter
- Remote Control
- Power Cable
- (4) x "AA" Batteries

## **Features:**

- Versatile High-Powered Mobile Cabinet Speaker System
- Rugged, Durable & Reliable Sound
- Wireless BT Music Streaming Ability
- Speaker System: 10" Woofer, 1" Tweeter
- Compression Driver with Titanium Diaphragm
- Built-in Rechargeable Battery
- 2-Way Full Range Audio Projection
- Built-in Digital Audio Amplifier
- RCA (L/R) Stereo Line Input Connectors
- RCA (L/R) Stereo Line Output Connectors
- Connect & Stream Audio from External Devices
- USB Flash Drive & SD Memory Card Readers
- USB Reader Doubles as Device Charging Port
- FM Radio with Digital LCD Display
- ID3 Tag Song Readout Info: LCD Displays Song Title/Song Artist
- Rear Panel Rotary Dial & Button Control Center
- Master Volume, Mic Volume, Echo, Treble, Bass Setting
- (2) 1/4" Microphone Inputs
- Convenient Carry Handles
- 35mm Speaker Stand Mount
- Engineered Heavy Duty ABS Housing

## **Technical Specs:**

- Power Output: 600 Watt
- Amplifier Class: D
- Impedance: 4 Ohm
- T.H.D.: <1%
- Sensitivity: 95dB (+/-2dB)
- Mic Input Level: <15mV
- Line Input/Output Level: >250mV
- Frequency Response: 100-18kHz
- Digital Audio File Compatibility: MP3, WMA
- Maximum SD/USB Flash Memory Support: 32GB
- Mic & Beltpack Battery Operated: Requires 2 x 'AA' Batteries (Each)
- Power Supply: 120-240V
- Dimension (L x W x H): 14.8" x 12.4" x 21.7" -inches

# PYLE

PyleUSA.com



**VISIT US ONLINE:**

*Have a question?*

*Need service or repair?*

*Want to leave a comment?*

[PyleUSA.com/ContactUs](http://PyleUSA.com/ContactUs)

PYLE

**Questions? Issues?**

We are here to help!

Phone: (1) 718-535-1800

Email: [support@pyleusa.com](mailto:support@pyleusa.com)