

PYLE
PyleUSA.com

PYLE
PyleUSA.com



VISIT US ONLINE:
Have a question?
Need service or repair?
Want to leave a comment?
PyleUSA.com/ContactUs

PYLE

Questions? Issues?

We are here to help!
Phone: (1) 718-535-1800
Email: support@pyleusa.com











PPHP1243B
12" Portable Wireless BT PA Speaker System
Karaoke Speaker with Latest DJ LED Lights,
USB/FM/BT/Aux/Remote Control/Mic Inputs,
Built-in Rechargeable Battery (800 Watt)

USER MANUAL

**PLEASE READ THE INSTRUCTION MANUAL CAREFULLY
AND KEEP IT FOR FUTURE REFERENCE**


WARNING

-  1. **DO NOT** place objects on top of the device, as objects may scratch the device.
-  2. **DO NOT** expose the device to dirty or dusty environments.
-  3. **DO NOT** insert any foreign objects into the device.
-  4. **DO NOT** expose the device to strong magnetic or electrical field.
-  5. **DO NOT** use the device in the rain
-  6. Please check with your Local Authority or retailer for proper disposal of electronic products.
-  7. **DO NOT** disassemble the device. Only a certified service technician should perform repair.
-  8. The device has apertures to disperse heat. **DO NOT** block the device ventilation, the device may become hot and malfunction as a result.

Illegal operation may cause personal injury, which could be fatal and may cause damage to property.

REMOTE CONTROL Functions


1. STANDBY BUTTON
2. CHOOSE INPUT AUX/FM/BT/USB SIGNAL
3. MUTE BUTTON
4. PLAY/STOP BUTTON ON MP3 MODE, SCAN FUNCTION ON FM MODE
5. NEXT SONG ON USB/MICRO SD MEMORY CARD, NEXT CHANNEL ON FM MODE
6. PREVIOUS SONG ON USB/MICRO SD MEMORY CARD, LAST CHANNEL ON FM MODE
7. EQ EFFECT ON MP3 MODE
8. INCREASE SPEAKER VOLUME
9. CHOOSE SONG NUMBER DIRECTLY ON MP3 MODE
10. STOP BUTTON
11. DECREASE MUSIC VOLUME
12. REPEAT SONG ON USB/MICRO SD MEMORY CARD



TWS-TRUE WIRELESS STEREO SETUP

1. Turn on two same PA speaker that you're attempting to pair together and switch both units to Wireless BT mode.
2. Choose one of units to begin to pairing process.
3. Press down on the PLAY ►|| button for 3 seconds until you hear a chiming sound; This means the unit is ready to pair with another unit.
4. Move onto the second unit and repeat step 3.
5. Now begin playing your music through Wireless BT enabled mobile device. The speakers will begin to play your music simultaneously.

Control Board Functions



1. USB Control Board
2. USB and Micro SD Memory card Input Jack
3. Master Volume Control Knob
4. 3.5MM AUX Input Jack
5. Short press to choose input signal, press and hold to turn OFF/ON light
6. Turning to the end left is power off, then turn it to the right end is power on
7. Echo Volume Control Knob
8. Microphone Volume Control Knob
9. Charge LED Indicator, RED color is charging mode, BLUE color is full charge
10. DC 5V Input Jack
11. 6.5MM Microphone Input Jack

Troubleshooting and Warning

Fault	Possible Cause	Solution
No sound	1. No input sound source 2. Volume is too low	1. Use a better music signal 2. Adjust volume
Distortion of sound	1. Volume too high 2. Speaker may be damaged	1. Turn down the volume 2. If speaker is damaged, Repair or replace it
Karaoke does not work	1. Microphone plug is not fully inserted. 2. Microphone switch is not on 3. Microphone volume knob is at the lowest position	1. Plug microphone properly into the socket 2. Turn on microphone switch 3. Adjust microphone volume properly
MP3 does not play	1. The song format in the U disc is incorrect 2. Improper operation has caused a process disorder 3. USB disc is disconnected	1. Transform song format into Mp3 format 2. Reboot the machine 3. Insert USB disc properly

PPHP1243B

12" Portable Wireless BT PA Speaker System

Karaoke Speaker with Latest DJ LED Lights, USB/FM/BT/Aux/Remote Control/Mic Inputs, Built-in Rechargeable Battery (800 Watt)

Features:

- True Wireless Stereo Function
- Portable PA Speaker System
- High-Powered Loudspeaker Design
- Wireless BT Music Streaming Ability
- Multi-Color Flashing LED Party Lights
- Built-in Rechargeable Battery
- LED Display
- USB/FM/Remote Control/Microphone Inputs
- Master Volume, Mic Volume, and Mic Echo Adjustable



WARNING:

This products can expose you to a chemical or group of chemicals, which may include "Lead and lead compounds" which is known in the state of California to cause cancer, birth defects, or other reproductive harm. For more info, go to <https://www.p65warnings.ca.gov/>.