

**PYLE**  
PyleUSA.com



**VISIT US ONLINE:**  
*Have a question?*  
*Need service or repair?*  
*Want to leave a comment?*  
[PyleUSA.com/ContactUs](http://PyleUSA.com/ContactUs)

**PYLE**

**Questions? Issues?**

We are here to help!

Phone: (1) 718-535-1800

Email: [support@pyleusa.com](mailto:support@pyleusa.com)



**PPHP101WMB**  
(600 Watt MAX)



**PPHP121WMB**  
(800 Watt MAX)



**PPHP127B**  
(800 Watt MAX)



**PPHP128B**  
(800 Watt MAX)

**Wireless BT Portable PA Speaker**  
Portable PA & Karaoke Party Audio Speaker  
with microphone, Built-in Rechargeable Battery,  
Flashing Party Lights, MP3/USB/FM Radio

**User Manual**

## WARNING



1. **DO NOT** place objects on top of the device, as objects may scratch the device.



2. **DO NOT** expose the device to dirty or dusty environments.



3. **DO NOT** insert any foreign objects into the device.



4. **DO NOT** expose the device to strong magnetic or electrical field.



5. **DO NOT** use the device in the rain



6. Please check with your Local Authority or retailer for proper disposal of electronic products.




7. **DO NOT** disassemble the device. Only a certified service technician should perform repair.



8. The device has apertures to disperse heat. **DO NOT** block the device ventilation, the device may become hot and malfunction as a result.

**Illegal operation may cause personal injury, which could be fatal and may cause damage to property.**

## CONTROL BOARD FUNCTIONS



1. Power Switch

2. Master volume control

3. DC 9V input jack/charge LED indicator red color is **ON** in charging mode, light off is full charge mode.

4. Bass volume control knob

5. Treble volume control knob

6. Microphone Echo control knob

7. USB and Micro SD Memory card slot


8. 3.5mm AUX input jack

9. 6.5mm Microphone input jack

10. LED light switch

11. Microphone volume control knob
12. Display screen
13. Mode button: Short press to select BT, FM, AUX, USB, SD mode; Press & hold to start power saving mode, press and hold again to quit power saving mode.
14. Previous
15. Play/Pause/Press and hold for TWS function
16. Next
17. Press to start recording, short press again to save. Press and hold to play recorded files. Press and hold again to quit recording.
18. Short press to start microphone priority/When playing recorded file, press and hold to delete current recording.

### REMOTE CONTROL FUNCTIONS



### REMOTE CONTROL FUNCTIONS

1. **Power:** Used to turn on/off the MP3 player power.
2. **MODE:** Used to switch the AUX/USB/BT/Radio
3. Mute button
4. In FM mode, press to search radio station automatically and save.
5. Next song in USB/In FM mode, short press to select saved radio station.
6. Previous song in USB//In FM mode, short press to select last frequency, press and hold to fast forward frequency.
7. EQ solution
8. Repeat song
9. Increase volume
10. Decrease volume
11. Play/Pause/In FM Mode, press to select saved radio station.
12. Choose song number directly/In FM mode, choose FM frequency directly

### TWS FUNCTION

**For increase sound effect, our unit provides TWS function as follows:**

**Step-1:** Turn ON BT mode on your device and connect the machine.

**Step-2:** Press and hold each control board "TWS" button more than 3's, and you will see "ON" on display, unit will start to connect the other unit automatically, now you can enjoy stereo sound, and adjusting one unit volume will affect the other unit.

#### Remark:

1. After connection, press and hold again one of control board "TWS" button more than 3's, you will see "OFF" on display, unit's TWS dis-connection.

## TROUBLESHOOTING

Fault	Possible Cause	Solution
No sound	<ol style="list-style-type: none"> <li>1. No input sound source.</li> <li>2. Volume is too low.</li> </ol>	<ol style="list-style-type: none"> <li>1. Use a better music signal.</li> <li>2. Adjust volume.</li> </ol>
Distortion of sound	<ol style="list-style-type: none"> <li>1. Volume too high.</li> <li>2. Speaker may be damaged</li> </ol>	<ol style="list-style-type: none"> <li>1. Turn down the volume.</li> <li>2. If speaker is damaged, repair or replace it.</li> </ol>
Karaoke does not work	<ol style="list-style-type: none"> <li>1. Microphone plug is not fully inserted.</li> <li>2. Microphone switch is not on.</li> <li>3. Microphone volume knob is at the lowest position.</li> </ol>	<ol style="list-style-type: none"> <li>1. Plug microphone properly into the socket.</li> <li>2. Turn on microphone switch.</li> <li>3. Adjust microphone volume properly.</li> </ol>
MP3 does not play	<ol style="list-style-type: none"> <li>1. The audio format in the U disc is incorrect.</li> <li>2. Improper operation has caused a process disorder.</li> <li>3. USB disc is disconnected.</li> </ol>	<ol style="list-style-type: none"> <li>1. Convert audio format into Mp3 format.</li> <li>2. Reboot the machine.</li> <li>3. Insert USB disc properly.</li> </ol>

### Wireless BT Streaming:

- Built-in BT for Wireless Music Streaming
- Simple & Hassle-Free Pairing
- Works with All of Today's Latest Devices
- Smartphones, Tablets, Laptops, Computers, etc.
- Wireless BT Version: 5.0
- Wireless BT Network Name: 'PYLEUSA'
- Wireless Range: Up to 32' ft.



WARNING:

This product can expose you to a chemical or group of chemicals, which may include "Lead and lead compounds" which is known in the state of California to cause cancer, birth defects, or other reproductive harm. For more info, go to <https://www.p65warnings.ca.gov/>.



**PPHP101WMB**  
(600 Watt MAX)



**PPHP121WMB**  
(800 Watt MAX)



**PPHP127B**  
(800 Watt MAX)



**PPHP128B**  
(800 Watt MAX)

### Features:

- True Wireless Stereo System
- Portable Speaker System
- High-Powered PA Loudspeaker Style
- Wireless BT Music Streaming Ability
- Multi-Color Flashing LED Party Lights
- Built-in Rechargeable Battery
- FM Radio with Digital LED Display
- Connect & Stream Audio from External Devices
- Aux (3.5mm) Input Connector Jack
- USB Flash Memory Reader
- Micro SD Card Reader
- 6.5mm Microphone input
- Battery Level LED Indicator Lights
- Recording Function
- Microphone Priority Function
- Microphone Echo Adjust Knob
- Bass & Treble Adjust Knobs
- Power saving mode to play music longer time
- With two wireless microphones
- Rugged & Durable Molded Cabinet Design
- Convenient Trolley & Wheels
- For Indoor / Outdoor Use



**PPHP101WMB**  
10" Wireless BT Portable PA Speaker  
(600 Watt MAX)

### What's in the Box:

- PA Speaker System
- Remote Control
- Power Adapter
- Two wireless microphones
- AUX cable

### Technical Specs:

- Construction Material: Polypropylene (PP)
- Max Power Output: 600 Watt Max
- Sound System: 10" -inch Subwoofer + 1" Tweeter
- USB Interface Type: 2.0
- Digital Audio File Support: MP3
- Maximum USB Flash Support: 32GB
- Remote Control Battery Operated, 1 Piece Button Cell Battery CR-2025 (Included)
- Battery Life: Up to 3.5 Hours (Charge Time: Approx. 5 Hours)
- Rechargeable Battery: 7.4V, 3600mAh – 26.64 Wh
- Power Supply: 120/240V, Switchable (9V/1.33A Power Adapter)
- Product Dimensions (L x W x H): 11.8" x 9.4" x 19.3" -inches

### Features:

- True Wireless Stereo System
- Portable Speaker System
- High-Powered PA Loudspeaker Style
- Wireless BT Music Streaming Ability
- Multi-Color Flashing LED Party Lights
- Built-in Rechargeable Battery
- FM Radio with Digital LED Display
- Connect & Stream Audio from External Devices
- Aux (3.5mm) Input Connector Jack
- USB Flash Memory Reader
- Micro SD Card Reader
- 6.5mm Microphone input
- Battery Level LED Indicator Lights
- Recording Function
- Microphone Priority Function
- Microphone Echo Adjust Knob
- Bass & Treble Adjust Knobs
- Power saving mode to play music longer time
- With a wireless microphone
- Rugged & Durable Molded Cabinet Design
- Convenient Trolley & Wheels
- For Indoor / Outdoor Use



**PPHP121WMB**  
12" Wireless BT Portable PA Speaker  
(800 Watt MAX)

### What's in the Box:

- PA Speaker System
- Remote Control
- Power Adapter
- Wireless microphone
- AUX cable

### Technical Specs:

- Construction Material: Polypropylene (PP)
- Max Power Output: 800 Watt Max
- Sound System: 12" -inch Subwoofer + 1" Tweeter
- USB Interface Type: 2.0
- Digital Audio File Support: MP3
- Maximum USB Flash Support: 32GB
- Remote Control Battery Operated, 1 Piece Button Cell Battery CR-2025 (Included)
- Battery Life: Up to 3 Hours (Charge Time: Approx. 5 Hours)
- Rechargeable Battery: 7.4V, 3600mAh – 26.64 Wh
- Power Supply: 120/240V, Switchable (9V/1.33A Power Adapter)
- Product Dimensions (L x W x H): 14" x 11.4" x 21.7" -inches

### Features:

- True Wireless Stereo System
- Portable Speaker System
- High-Powered PA Loudspeaker Style
- Wireless BT Music Streaming Ability
- Multi-Color Flashing LED Party Lights
- Built-in Rechargeable Battery
- FM Radio with Digital LED Display
- Connect & Stream Audio from External Devices
- Aux (3.5mm) Input Connector Jack
- USB Flash Memory Reader
- Micro SD Card Reader
- 6.5mm Microphone input
- Battery Level LED Indicator Lights
- Recording Function
- Microphone Priority Function
- Microphone Echo Adjust Knob
- Bass & Treble Adjust Knobs
- Power saving mode to play music longer time
- With wired microphone
- Rugged & Durable Molded Cabinet Design
- Convenient Trolley & Wheels
- For Indoor / Outdoor Use



**PPHP127B**  
12" Wireless BT Portable PA Speaker  
(800 Watt MAX)

### What's in the Box:

- PA Speaker System
- Remote Control
- Power Adapter
- Wired microphone

### Technical Specs:

- Construction Material: Polypropylene (PP)
- Max Power Output: 800 Watt Max
- Sound System: 12" -inch Subwoofer + 1" Tweeter
- USB Interface Type: 2.0
- Digital Audio File Support: MP3
- Maximum USB Flash Support: 32GB
- Remote Control Battery Operated, 1 Piece Button Cell Battery CR-2025 (Included)
- Battery Life: Up to 3 Hours (Charge Time: Approx. 5 Hours)
- Rechargeable Battery: 7.4V, 3600mAh – 26.64 Wh
- Power Supply: 120/240V, Switchable (9V/1.33A Power Adapter)
- Product Dimensions (L x W x H): 14 "x 11.4 "x 21.7 " -inches

### Features:

- True Wireless Stereo System
- Portable Speaker System
- High-Powered PA Loudspeaker Style
- Wireless BT Music Streaming Ability
- Multi-Color Flashing LED Party Lights
- Built-in Rechargeable Battery
- FM Radio with Digital LED Display
- Connect & Stream Audio from External Devices
- Aux (3.5mm) Input Connector Jack
- USB Flash Memory Reader
- Micro SD Card Reader
- 6.5mm Microphone input
- Battery Level LED Indicator Lights
- Recording Function
- Microphone Priority Function
- Microphone Echo Adjust Knob
- Bass & Treble Adjust Knobs
- Power saving mode to play music longer time
- With wired microphone
- Rugged & Durable Molded Cabinet Design
- Convenient Trolley & Wheels
- For Indoor / Outdoor Use



**PPHP128B**  
12" Wireless BT Portable PA Speaker  
(800 Watt MAX)

### What's in the Box:

- PA Speaker System
- Remote Control
- Power Adapter
- Wired microphone

### Technical Specs:

- Construction Material: Polypropylene (PP)
- Max Power Output: 800 Watt Max
- Sound System: 12" -inch Subwoofer + 1" Tweeter
- USB Interface Type: 2.0
- Digital Audio File Support: MP3
- Maximum USB Flash Support: 32GB
- Remote Control Battery Operated, 1 Piece Button Cell Battery CR-2025 (Included)
- Battery Life: Up to 3 Hours (Charge Time: Approx. 5 Hours)
- Rechargeable Battery: 7.4V, 3600mAh – 26.64 Wh
- Power Supply: 120/240V, Switchable (9V/1.33A Power Adapter)
- Product Dimensions (L x W x H): 14 "x 11.8 "x 21.7 " -inches