

Visit Our Website



SCAN ME
PyleUSA.com

PYLE

PyleUSA.com



Wireless BT Streaming PA Speaker & Amplifier Mixer System Kit

USER GUIDE

**READ ALL INSTRUCTIONS CAREFULLY BEFORE USING THIS PRODUCT.
RETAIN THIS OWNER'S MANUAL FOR FUTURE REFERENCE.**

FEATURES:

- All-in-One DJ Audio Loud-Speaker Kit
- 8-Channel Powered Amplifier Audio Mixer
- Dual Molded Cabinet PA Speakers
- Sound System: (2) x 8" Subwoofers, (2) x 1" Piezo Horn Tweeters
- Rugged, Durable & Reliable Sound
- Bluetooth Wireless Music Streaming Ability
- Compression Drivers with Titanium Diaphragms
- 2-Way Full Range Audio Projection
- Built-in Digital Audio Amplifier
- Independent Channel Audio Configuration Settings
- Audio Mixer Console Button Control Center
- 5-Band Graphic EQ Control
- +48V Phantom Power Switch
- USB Flash Drive Memory Reader
- ID3 Tag Song Readout Info: LCD Displays Song Title/Song Artist
- Connect & Stream Audio from External Devices
- XLR (3-Pin) Connectors
- 1/4" (6.35mm) Input
- RCA (L/R) Stereo Line Input/Output Jacks
- Heavy Duty Engineered ABS Housing
- Convenient System Design Assembles & Disassembles for Quick Setup
- Perfect for On-Stage Performances, Crowd Control, Public Gathering Events

BLUETOOTH CONNECTIVITY:

- Instantly Stream Music from Your Bluetooth Devices
- Works with All Your Favorite Bluetooth Devices
(iPhone, Android, Smartphone, iPad, Tablet, PC, etc.)
- Bluetooth Version: 4.0
- Bluetooth Network Name: 'BLUE'
- Wireless Range: Up to 30'+ ft.

WHAT'S IN THE BOX:

- (2) 8" PA Speakers
- Audio Mixer Console
- Speaker Connection Cables (1/4")
- Power Cable

TECHNICAL SPECS:

- Power Output: 600 Watt MAX
- Speaker Style: Molded Cabinet
- Magnet: 20 Oz
- Voice Coils: 1.0" -inch
- Amplifier Class: D
- Impedance: 4 Ohm (x2)
- T.H.D.: <1%
- Sensitivity: 98dB (+/-2dB)
- Mic Input Level: <15mV
- Line Input/Output Level: >250mV
- Frequency Response: 40-18kHz
- Digital Audio File Compatibility: MP3, WMA
- Maximum SD/USB Flash Memory Support: 32GB
- Remote Battery: Requires (1) x 'CR20-25' Button Cell, Included
- Power: 110/220V
- Unit Dimensions (L x W x H): 27.4" x 12.8" x 23.8" -inches



In order to achieve the best performance of your product, please read this instruction manual carefully before using, and keep it for future reference.



CAUTION
RISK OF ELECTRIC
SHOCK, DO NOT
OPEN



Caution: To reduce the risk of electric shock, do not open this device. There are no serviceable parts for customers. Please refer any maintenance or repair to qualified personnel.



This sign means the existence of dangerous voltage inside the unit, which presents a risk of electric shock.



This sign means that there are important instructions for operation and handling in the manual that comes with this device.

IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS

⚠ WARNING: Cancer and Reproductive Harm - www.P65warnings.ca.gov

WARNING:

When using electric products, basic precautions should always be followed, including the following:

- **Read all instructions before using the product.**
- Do not use this product near water, i.e., a bathtub, sink, wet basement, or swimming pool.
- This product, in combination with other headphones and speakers, may be capable of producing sound levels that could cause permanent hearing loss. Do not operate for long periods at a high volume level or any level that is uncomfortable. If you experience any hearing loss or ringing in the ears, consult a doctor.
- The product should be located away from heat sources such as radiators, heat registers, or any other product that produces heat.
- The product should be connected to a designated power supply described in these instructions.
- The power supply cord should be unplugged when left unused for a long period of time.
- Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through its openings.
- **The product should be serviced by qualified personnel when:**
 1. The power supply cord or plug has been damaged
 2. Objects have fallen, or liquid has been spilled into the product
 3. The product has been exposed to rain
 4. The product does not appear to operate normally or exhibits a marked change in performance
 5. The product has been dropped, or the enclosure damaged
- Do not attempt to service the product beyond what is described in the user-maintenance instructions. All other servicing should be performed by qualified service personnel.

INSTRUCTIONS

Before connecting the speaker, make sure the system is off and the controls are at the minimum level. Otherwise, the system could be damaged:

1. Plug the AC plug into an electrical outlet and to the speaker.
2. Plug the microphone into the "MIC" input with a 1/4-inch connector or Canon (XLR).
3. Plug an auxiliary system (CD, DECK, MP3, DVD, etc.) into the "LINE IN" input.
4. Turn on the systems. A green LED will light up on the speaker to indicate it is on.
5. Set the volume at the middle level on the MIC and LINE IN inputs.
6. Gradually increase the master volume.
7. Adjust the 5-band EQ controls to equalize the sound.


CAUTION

- Instructions are intended to alert the user to the risk of injury or material damage if the unit is used improperly.
- Material damage refers to damage or other adverse effects caused concerning the home and all its furnishings, as well as to domestic animals or pets.

CONTROLS

1. **MP3 PLAY**
2. **USB input**
3. **5-BAND EQUALIZER:** Super musical 5-band equalizer for the output channel.
4. **MICROPHONE INPUT:** Connector for a balanced microphone.
5. **TREBLE:** This knob adjusts the treble.
6. **BASS:** This knob adjusts the bass.
7. **EFFECT:** This knob controls the signal level sent to the internal digital delay effect.
8. **VOLUME CONTROL:** Use this to set the volume level.
9. **AUX IN:** Allows a cassette recorder or CD player to connect to the main output.
10. **CHANGE INPUT SOURCE:** There are 2 input sources to choose from: AUX IN and MP3.
11. **POWER INDICATOR**

CONTROLS



BLUETOOTH OPERATING PROCEDURES

Step 1

Push the "MODE" button until you find "BLUE" on the display.

Step 2

Turn on the smartphone's Bluetooth function and search for the speaker box. Connect to "Bluetooth" (no password is required to finalize the connection between the smartphone and the speaker box).

Step 3

Once the Bluetooth is connected between the smartphone and the speaker box, play the music on the smartphone and enjoy the powerful sound from the speaker box!

CLEANING AND STORAGE

Cleaning

Unplug the unit before cleaning. Use a soft, dry cloth to clean the exterior. Do not use any solvents, chemicals, or abrasive cleaning materials.

Storage

Store the unit in a cool, dry place. Avoid exposing the unit to direct sunlight, high temperatures, or moisture. When storing for an extended period, ensure all cables are neatly coiled and secured to prevent damage.

Register Product

Thank you for choosing PyleUSA. By registering your product, you ensure that you receive the full benefits of our exclusive warranty and personalized customer support.

Complete the form to access expert support and to keep your PyleUSA purchase in perfect condition.



[PyleUSA.com/register](https://www.PyleUSA.com/register)

PYLE

PyleUSA.com



Questions or Comments?

We are here to help!

Phone: 1.718.535.1800

PyleUSA.com/ContactUs