

PSLBZ18

STICKY INSECT TRAP WITH UV LIGHT

User Manual



Flying insects are attracted to the special ultra violet light that is irresistible to flying insects. Once attracted into the device, they will come to rest on a special adhesive coated glue board and become permanently captured. Once the board is full, it can quickly and easily be replaced. Elegant design, no chemical substances, no pollution, odorless, noiseless and safe.


Time to replace the glue board paper: replace the glue board paper per month, but replace it immediately when insects are full.

WARNING:

- Indoor Use only!
- Never carry the appliance by the cord.
- Do not use any extra devices that are not supplied along with the appliance.
- Only connect the appliance to an electrical outlet with the Voltage and frequency mentioned on the appliance label.
- Avoid overloading.
- Always remove the plug from the socket when filling or cleaning the appliance.
- Children can not play with it.
- Cannot be used in garage, stable or similar conditions.
- Keep away from flammable.
- The appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Keep the appliance and its cord out of reach of children less than 8 years.
- Children should be supervised to ensure that they do not play with the appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

INSTRUCTIONS:

- Put the plug into the socket.
- The UV-A tube should light now.
- If you do not use the appliance for an extended period, remove the plug from the electrical socket.



VISIT US ONLINE:

Have a question?
Need service or repair?
Want to leave a comment?

PyleUSA.com/ContactUs

PYLE