









Note: Press and turn the key CLOCKWISE to lock. Press and turn the key COUNTER-CLOCKWISE to unlock.