

PYLE®

www.PyleAudio.com



DISCOJAM 2

PSUFM1070P

Bluetooth Active-Powered Speaker System

USER MANUAL

Specifications

- * Dual 10" Woofers and Two 3" Piezo Tweeters
- * Heavy Duty Handles for Easy Portability
- * Three Color Flashing DJ lights on Tweeters and Woofers
- * LED Sound Level Indicators
- * Works with Most Amplifiers or With The Disco Jam Active Models
- * Speaker Spring Terminals
- * Ported Enclosure for Added Bass Response
- * Power Handling: 1500 watts peak /750 Watt RMS @4 Ohms
- * Woofer Magnet Weight: 25 oz.
- * Sensitivity (1w/1m): 90dB
- * Built In Crossover Network: 3.5k Hz
- * Frequency Response: 20 Hz - 20 kHz
- * 35mm Speaker Stand Mount
- * Dimensions: 36.8"(H) x 15.2"(W) x 13.6"(D)
- * Weight: 32 lbs

Safety Notes

1. Correct power must be used to operate this unit properly, do not use any other powering options, cords or methods.
2. Carefully handle, plug and unplug the power cable when handling. Hold the plug with a firm grip and when plugging or unplugging from sockets.
3. Do not open chassis! Extermely dangerous! Do not put your hands inside the chassis. If the device begins to malfunction do not attempt to repair, unplug the unit and contact Pyle immediately.
4. Don't use volatile or dangerous chemical cleaners on the unit (like toluene, alcohol, gasoline etc.) Use gentle cleaners.
5. Keep the unit in a well ventilated environment and keep away from, direct sunlight to prevent unit from overheating.
6. Protect the unit from moisture or rain.

Speaker Board Schematic



① Type of sticker

⑤ Vent Hole

② Tweeters

⑥ Speaker machine feet

③ Woofer confinement

⑦ Speaker handle

④ Woofer Speaker

DISCOJAM **2**



tel: 718.535.1800 fax: 718.236.2400

1600 - 63rd Street Brooklyn, N Y, 11204

www.PyleAudio.com