

ELECTRONIC DRUM KIT



INSTRUCTION MANUAL

Dear Customer

Thank you sincerely for buying our hand roll drum kit. We are specialized in developed and manufactured hand roll drum kit and piano for over 15years. This hand roll drum kit is a handy size product which is very easy to carry, in order to have a bast experience affect, please pay attention to the operation, wish you enjoy it, thanks again for your cooperation!

I. Specification:

- 7 drum pad: (Include crash cymbal, ride cymbal, open/close hi-hat, snare, high tom, low tom-tom, floor tom-tom) 9 drum pad: (include 2 crash cymbal, ride cymbal, open/close hi-hat, snare, base drum, high tom-tom, low tom-tom, floor tom-tom) 2 drum pedals: (include 1 hi-hat, 1 base drum)
- 2. 12demo songs, 7drum sounds, accompaniment
- 3. Volume Control: lever 9
- 4. Speed Control:lever 15
- 5. Could record and play
- Audio input,match your cell phone, tablet, PC and other device which could support music.
- 7. With speaker, using as stereo

II. Features:

- 1. The world's first Multinational, portable, and professional drum
- 2. Fit for family entertainment/friends gathering and drum practice
- 3. Multi-sounds, simulated the really drum kits
- The standard drum configuration and the extension for foot pedal could bring you real-life drum experience
- Include accompaniment/ demo songs, control the playing speed free, this is the best choice for drum learning
- 6. Include recording function, get all your inspiration in record easily
- 7. With two high-quality stereo speakers
- 8. Audio input, chose any music you like to practice
- 9. Could connect with your earphone, will not disturb others when you using this.
- 10. Support to connect a external speaker, the sounds will be much shocking
- USB MIDI port, connect PC to play with all the Midi software and electronic drum games, MIDI software like: Sonar, Cubase, Nuendo, Ezdrummer (this only work If the model includes MIDI function)

III. Accessories:

Drum Kits*1, Pedals*1, Manual*1, USB Cable*1, 3.5Audio Cable*1, Drum Stick*2

IV. The appearance of drum kits 10 6 17 High tom Low-mid tom High tom Low-mid tom Ride cymbal Crash Crash cymbal Crash cymbal Open/Close hi-hat Ride cymbal Snare Low floor tom Bass drum Snare Open/Close hi-hat Low floor tom 7 Pad drum 9 Pad drum V. Device connecting map Pedal Pedal hi-hat Bass drum 6

Pedal

Usb adapter

Earphone or

Stereo

(select to connect)

Cellphone or

Computer or tablet

(select to connect)

VI.Function Description

No.	Name	Function Description	
1	ON/OFF	Battery power switch	
2	USB/DC 5V	USB port for power, by AC adapter or power bank	
3	FOOT PEDAL	Pedals for Hi-Hat and Bass Drum	
4	HEAD PHONE	Audio output interface	
5	Мр3	Audio input interface	
6	VOL-	Volume down	
7	VOL+	Volume up	
8	STYLE	Recycle Three different drum sounds	
9	DEMO	Recycle demo songs	
10	REC	Press "REC" ,when the LED light, the device could record	
11	PLAY	Play the recording	
12	RHY	Play accompaniment	
13	START/STOP	Start to play/stop playing accompaniment the recording demo songs	
14	Tall	Control the playing speed of demo songs and accompaniment	
15	T+	Control the playing speed of demo songs and accompaniment	
16	POWER LED	Plug in the power adapter, the LED light	
17	RECLED	Press "REC ",the LED light	

VII.Pedal Instruction

- This drum kits support one pedal Hi-hat and one bass drum as ,both of them
 were single channel input.
- 2.When the pedal doesn't plug into the "FOOT PEDAL" jack, Sounds will be Open hi-hat if you click "Open/close Hi-hat"; When you inject the pedal in jack ,sounds will be Close hi-hat if you step on the pedal; Sounds will be Open hihat while you step off.
- Once you inject the pedal in the side FOOT PEDAL jack, one of the pedal has "Bass drum" function, the other one is functioned for "Pedal Hi-hat"; If you need Bass drum when you playing, you have to step on the specified pedal.


Mark: The pedal can not use mutually, for each one has its specified function

VIII.POWER ON/OFF

- 1. When you Switch on, you can tell from the LED light that this drum can be used.
- 2. After you switch on the drum kits, you can change the volume as you need.

IX.USB MIDI function (only work if the model with MIDI function)

- When you completely connecting the usb cable between the drum kits and computer, the MIDI Date could transmit well
- 2.If you need transmitting USB Date ,you should finish below step carefully
 *Please use standard usb cable
 - *Compatible with Win XP/Vista/7/8 and Mac OSX, drive free and hot plug supporting
- *Compatible with Sonar, Cubase, Nuendo, Ezdrummer, Etc., major Sequencer software and VST/VSTi and all kinds of MIDI Drum kits games.



Note: The drum kit will enter into sleep situation without any action after 1 minute, wake up it by playing any pads.

X. Troubleshooting

Failure phenomenon	Reason	Solution
Power indicator does not work	External power adapter is not plugged well or USB cable is not isserted well	Please check the external power cable
Abnormal sound	External power adapter Voltage shortage	Please Change another external power adapter
Pedal does not work	The interface is not connecting well	Please completely plug it
No sounds (Headphone or audio)	No power supply volume is not adjusted well earphone not connected to the right interface of our drum	Please check the level of VOL and make sure all the interface are connected well

i.Cautions:

- 1. Do not use the piano in a wet, high temperature or dusty area
- Keep the drum kit level when in use, Do not place the drum kit near areas with strong electric waves
- 3. Do not place the heavy objects on the product, to avoid impacting of the collision
- 4 .Do not pull or twist the body or drum kits with 90, it may damage the function,
- Do not tamp with the wiring of this product with a cutter or other sharp tools, it may damage the functions.
- 6. When rolling up the drum kits after use, do not roll up too tight.

ii.Specification:

- Product size: 422(L)*325(W)*62(H)MM
- 2. Weight: 680G
- 3. Input: USB DC 5 V/2000MA
- 4. Material: Silicone



