

PYLE

PyleUSA.com



PWMA63

Portable Radio & PA Speaker System
Compact Headset Microphone Amplifier

User Manual

FUNCTION

- **[Digital song]** input numbers to select songs, supports 1-9999 preferred song.
- **[MP3 player]** direct Micro SD Memory Card broadcast and U disk MP3 files, supports MP3, WMA, WAV music formats.
- **[Digital recording]** built-in microphone, recording function.
- **[Lyrics]** support the display of song lyrics, synchronized display playback.
- **[FM Radio]** FM digital stereo radio, clock radios, radio broadcast memory, you can store 40 radio stations.
- **[Audio Input]** stereo audio input interface, easily connects to computers, digital music players, cellphones and other audio-visual products of various types of sources.
- **[Break-point memory]** plays the last track automatically.

Buttons, jacks function (subject to availability)

POWER ROTARY SWITCH/VOLUME CONTROL

1. **Switch:** counterclockwise rotation switch clicks, the display lights on, clockwise rotation switch again and clicks to shutdown.
2. **Volume adjustment:** counter-clockwise to increase the volume, clockwise to decrease the volume.
3. **ECHO Volume adjustment:** When using a microphone, clockwise to increase volume, counter-clockwise to decrease the volume.
4. **[MIC]:** microphone achieve access megaphone.
5. **[AUX]:** Audio input interface, connected to computers, digital music players, cell phones and other audio-visual products of various types of audio input
6. **[USB]:** insert USB to play MP3 music, supports up to 32G maximum.
7. **[MICRO SD]:** Insert Micro SD Memory Card to play MP3, supports up to 32G maximum.
8. **[DC 9V]:** power supply into the jack into the unit distribution 9V1A the charger, charging the battery icon flashing screen, after full battery icon does not flash
9. **[▶|◀]:** Play/Pause, enter the sub-menu state 9. short press to return to the previous level.
10. **[◀◀]:** previous song, press and hold to rewind.

11. **[▶▶]:** Next song, press and hold to fast forward.
12. **[M]:** Short press to confirm function, press to return to the main menu.
13. **[FM]:** Short press to enter FM/play/pause, press and hold to search radio stations and save
14. **[REC]:** Press when entering the record, press enter to save and play back recording, playback recording press Delete Record
15. **[1234567890]:** Enter the selected song numbers, select the radio station, select the frequency.

COMPUTER SPEAKERS CONNECTION

The AUX audio input interface, the distribution of the "audio signal line" end into the machine "AUX" jack and the other end into the computer's "Ω symbol" audio output jack, and computer speaker function.

HOW TO CHARGE

Insert 9V1A charger to DC 9V jack of the machine for charging, the battery icon will flash while charging. No worry about overcharge as the unit has overcharge protection circuit. It takes approx. 4-6 hours to fully charge the battery. Different volume will influence the battery life and battery indicator also will be biased.

LOW BATTERY

When low voltage battery occurs, the system will automatically shut down. Please charge the battery. The unit should be charged once a month if it has not been used for a long time.

SOLUTIONS TO COMMON PROBLEMS

1. **Automatic shut down:** the battery is low, please charge two hours before use.
2. **No sound speaker:** volume is turned on.
3. **No sound connected to the computer:** PC interface connection errors, check the correct computer's audio output connector.
4. **Key non-functional or functional fault:** power-cycle.

FEATURES:

- 3-in-1: Karaoke Speaker + Radio + Music Streaming
- Fun for Performers of All Ages!
- Use it Like a Megaphone & Project Your Voice
- Lightweight, Compact & Handheld Design
- FM Radio with Digital LCD Display
- Built-in Rechargeable Battery
- Headset Microphone Included
- Aux (3.5mm) Input
- Ability to Connect & Stream External Devices
- MP3 Digital Audio File Compatibility
- USB & Micro SD Memory Card Readers
- Front Panel Button Control Center

RECORDING ABILITY:

- Create Your Own Songs
- Ability to Record Your Voice & Music
- Easily Save & Share Your Music
- Save Files via USB Flash or Micro SD
- Digital Audio File Created: WAV

WHAT'S IN THE BOX:

- Headset Microphone
- Remote Control
- 9V Power Adapter Cable
- Convenient Carry Strap

TECHNICAL SPECS:

- Output Power: 10 Watt
- Full Battery Provides up to 6 Hours Operation
- Loudspeaker Driver: 3"
- Impedance: 4 Ohm
- S/N Ratio: >80dB
- Power Supply: 110/220V
- Digital Audio File Support: MP3, WMA, WAV
- MAX Flash Memory Support: 32GB
- Size: 5.5" x 5.2" x 1.9"

PYLE

PyleUSA.com



VISIT US ONLINE:

Have a question?

Need service or repair?

Want to leave a comment?

PyleUSA.com/ContactUs

PYLE

Questions? Issues?

We are here to help!

Phone: (1) 718-535-1800

Email: support@pyleusa.com