

SLKTR101 - SLKTB102 - SLKTG103

Portable and Foldable Playpen

Lightweight, Easily Collapsible, Play Yard Crib for Indoor and Outdoor Use, For Baby or Toddler



serenelife™

USER GUIDE

1. Instructions

The children's tent is an automatic pop-up model and does not need to be set up manually. This tent has two doors, which can be opened and closed.



Questions? Issues?

We are here to help!

Phone: (1) 718-535-1800

Email: support@pyleusa.com

2. Features and Accessories


- The accessories include a top cover and an outer cover, which can effectively block the sun and waterproof, and provide a better playing and sleeping environment.
- The gauze material can provide better ventilation and vision.
- When used outdoors, ground nails and wind ropes can better fix the tent and protect safety.



3. How to Assemble



1. Open the half corners of the tent



2. Spread out the account



3. Hold with both hands and lift it up



4. Put down when it comes to the top



5. Gently shake the tent



6. Tent construction is complete

Tent Storage



1. Hold the tent's two short poles with both hands.
2. Press both hands at the same time
3. The tent is collapsed after pressing down.



4. Fold the tent to stretch the joints outward.
5. When the pinhole appears outward, then fold in half.
6. Tie it into a bag after rolling it.



4. Note

Hold the two short poles of the tent with both hands, press both hands at the same time.

