

SereneLife



SLOHT52

electric patio heater

user guide

visit our website



SCAN ME
serenelifehome.com

PLEASE KEEP THIS MANUAL CAREFULLY FOR FUTURE REFERENCE. FOR HOUSEHOLD USE ONLY.

Features:

- High Rated Aluminum Reflector
- High-Efficiency Carbon Fiber Heating Elements
- Provides Infrared Heating Similar to Sunlight
- Includes Mesh Grille Front
- Odorless, No Gas or Propane Use
- Remote Control Standing Heater
- Dust-free and Waterproof Design
- Anodized Extruded Aluminum Alloy Housing
- Digital Display for Three Power Settings: Low, Medium, and High
- Safety Features Include Tip-over Safety Switch
- IP65 Approved
- Quiet Operation with Overheat Protection

What's in the Box:

- Electric Patio Heater
- Remote Control
- Cap
- (1) Allen Key
- (2) Screw M6x30
- (2) Screw M4x14

CALIFORNIA PROP 65 WARNING

WARNING:

This product may expose you to chemicals, which is known to the state of California to cause cancer, birth defects and other reproductive harm. Do not ingest.

For more info go to: www.P65warnings.ca.gov

Technical Specs:

- Construction Material: Aluminum Alloy Frame, Stainless Steel Base Cover
- Heating Method: Radiant
- Power Supply: 900W
- 3 Heat Levels: Low (300 Watts), Medium (450 Watts), High (900 Watts)
- Heating Area: 15 sq. ft.
- Maximum Amperage: 12.5 Amps
- Timer: 9 Hours
- Battery Operated Remote: 1.5V, (2) x 'AAA' Batteries (not included)
- Power Cable Length: 78.7" -inches, 120V
- Base Cover Size: 9" -inches (Diameter)
- Heat Warm Range: Around 5-10 Square Meters
- Product Dimensions (L x W x H): 9" x 9" x 37.40" -inches

PLEASE MAKE SURE TO READ THIS MANUAL CAREFULLY BEFORE USE.

IMPORTANT INSTRUCTIONS:

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. **Read all instructions before using this heater.**
2. Maintain at least 39" (100 cm) of clearance from walls and 12" (30 cm) from the ceiling.
3. Heater becomes hot during use. Avoid touching hot surfaces. Use handles if provided. Keep combustible materials like furniture, paper, clothes, and curtains at least 3 feet (0.9 meters) away from all sides.
4. Place the unit on a stable, flat, and horizontal surface.
5. The unit remains hot after shutdown. Do not touch it until fully cooled.
6. Do not place the unit near curtains or other flammable materials.
7. Do not cover the unit during or shortly after use.
8. Do not wrap the power cord around the unit.
9. Handle the unit with care. Avoid impact or vibration.
10. Ensure proper grounding during use.
11. Repairs must be performed by qualified professionals.
12. If the power cord is damaged, it must be replaced by the manufacturer or an authorized technician.
13. Do not place the heater directly below a power outlet.

14. During assembly, avoid flammable surfaces.
15. Do not use with a timer or switch that automatically powers on the heater—fire risk.
16. Not for use by individuals (including children) with reduced physical, sensory, or mental capabilities without supervision.
17. Supervise children to prevent misuse.
18. For household use only. Do not use in construction sites, barns, greenhouses, or areas with combustible dust.
19. The head of the unit gets hot. Unplug and allow it to cool before cleaning.
20. Not for bathroom, laundry, or wet area use. Never use near water.
21. Do not use in corrosive or volatile environments (e.g., dust, gas, steam).
22. Do not use as a drying rack.
23. Do not use as a sauna heater.
24. Do not use as a room heater for heat storage.
25. Do not use for animal breeding or raising.
26. Not intended for central hot air systems.
27. Do not immerse in water.
28. Use only with a clearly visible and accessible socket.
29. Do not run the cord under carpets, rugs, or furniture. Keep away from foot traffic.
30. To disconnect, turn off controls and unplug from outlet.
31. Use only as instructed in this manual. Improper use can cause fire or electric shock.
32. Plug directly into a wall socket. Do not use with extension cords or power strips.
33. Surface temperatures can get very hot. Keep children and pets at a safe distance.
34. Supervise children and dependent persons near the heater.
35. Always unplug when not in use.
36. Plug into a properly grounded outlet.
37. Keep foreign objects out of ventilation and exhaust openings.
38. Do not block air inlets or outlets. Do not use on soft surfaces like beds.
39. Do not use in areas with flammable liquids, gasoline, or paint.

SAVE THESE INSTRUCTIONS

CAUTION:

EXTEND OR UNFOLD LEGS BEFORE OPERATING.

PREPARATION

- 1. Unpack the box and check all accessories listed above. If anything is missing, contact the retailer.
- 2. Prepare a Phillips-head screwdriver.
- 3. Read this instruction manual carefully. Store it in a safe place for future use.



ACCESSORIES PACK CHECK LIST

Accessory Name	Qty	Accessory Name	Qty
Allen Key	1	Cap	1
Screw M6* 30	2	Screw M4* 14	2
Remote Controller	1		

PARTS DESCRIPTIONS

No.	Part Name	No.	Part Name	No.	Part Name
1	Main Body	4	Screw M6*30	7	Remote Controller
2	Base Cover	5	Cap		
3	Base	6	Screw M4*14		

PARTS DESCRIPTIONS



INSTALLATION

1. Remove the Main Body, Base, and Base Cover from the packaging.
2. Attach the Base Cover (#2) and Base (#3) to the bottom of the heater's main housing using Screw M6×30 (#4) and the provided Allen Key.
3. Attach the Handle (#5) to the main body using Screw M4×14 (#9).

OPERATIONS

1. Plug the unit into a wall socket. Ensure that the power supply matches the rated voltage.
2. The LED indicator light will begin flashing, indicating that the heater is in standby mode. Press the ON button on the remote control or the control panel to activate the heater. The heater will start at the low setting (1).


Each press of the power button will cycle through the following settings:

- Medium setting (2)
 - High setting (3)
 - Back to low setting (1)
3. When the heater is no longer needed, turn it off using the OFF button on the remote control or control panel, and then unplug the unit.

GROUNDING INSTRUCTIONS


This heater is intended for use with 120 volts. The plug is shown in Figure A. An adapter (Figure C) may be used to connect three-prong grounded plugs to two-slot receptacles. The green grounding lug must be connected to a permanent ground, such as a properly grounded outlet box. Do not use the adapter if a grounded three-slot receptacle is available.

Grounding Methods



CLEANING

- Always unplug the unit before cleaning.
- Wipe with a damp cloth. Do not use excessive water.
- Do not wrap or route the power cord during storage.
- For repairs or servicing, contact an authorized service technician only.



Register Product

Thank you for choosing SereneLife. By registering your product, you ensure that you receive the full benefits of our exclusive warranty and personalized customer support. Complete the form to access expert support and to keep your SereneLife purchase in perfect condition.

Start Here



Model Number:

SLOHT52

[Serenelifehome.com/pages/register](https://serenelifehome.com/pages/register)



questions? comments?

We are here to help!

Phone: 1.718.535.1800

[serenelifehome.com/contact us](https://serenelifehome.com/contact-us)