



Hurtle[™]

FLEETNESS

S10

8 Inch Foldable Electric Scooter

Upgraded Inflatable Tire
Foldable Commuter,
Suitable for Adult & Kids

USER MANUAL



Read the information supplied by the manufacturer.




Wear personal protective equipment.

For optimum performance and safety, please read these instructions carefully before operating the product.
Please keep this manual for future reference.

CONTENTS

| | |
|--|----|
| 1. General Information | 3 |
| 2. Product Overview | 4 |
| 2.1 General Information | 4 |
| 2.2 What you need to know | 4 |
| 3. Product Description | 4 |
| 3.1 How to Unfold | 4 |
| 3.2 How to Assemble | 5 |
| 3.3 How to Fold | 5 |
| 4. How to Ride | 6 |
| 5. SCOOTER SAFETY PRECAUTIONS | 8 |
| 6. Weight and Speed Limitations | 10 |
| 6.1 Weight Restrictions | 10 |
| 6.2 Speed Limits | 10 |
| 7. Operating Range | 10 |
| 8. Battery Information and Specifications | 11 |
| 9. Charging your Scooter | 12 |
| 10. Inspection, Maintenance, and Storage | 13 |
| 11. Scooter Specifications | 14 |

1. General Information



2. Product Overview

2.1 General information

The original scooter is an intuitive, technologically advanced solution. Using the latest technology and production processes, each scooter undergoes strict testing for quality and durability. With its lightweight, portable design, ease of use, range, and low carbon footprint.

2.2 What you need to know


Before you first experience your scooter, please read the **USER MANUAL** thoroughly and learn the basics to ensure your safety and the safety of others. The power will be shut down if nobody operate in five minutes, you need press power button before you ride.

⚠ WARNING: Failure to follow the basic instructions and safety precautions listed in the **USER MANUAL**, can lead to damage to your scooter, other property damage, serious bodily injury, and even death. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.


3. Product Description

3.1 How to unfold

1. Right hand presses down the back fender and the left hand pulls up the long pole until folding hook gets out of the hook hole on back fender.



2. Get the long pole stand up, then pull up the folding wrench towards the upright pole and force it to stay close to upright pole




3.2 How to assemble

The Smart Kick Scooter can be assembled within 2 minutes:


- Install the Handles and tighten the handles.

Before installing the handles, please make sure to differentiate the left & right handles carefully. Please see the difference of left & right handles from below images.




3.3 How to fold

1. Right index finger lift the buckle lock up, push the folding wrench outward with the thumb to put down the upright pole.



2. Press the upright pole down until the folding hook is fixed into the hook hole on back fender.



4. How to ride




Warning:


There is risk of falling down during learning, so make sure to wear helmet and protection kits all the time.

4.1 How to ride


1. Turn on the Scooter by press the Power key for 2 seconds and check the battery power.




2. Once the power is on it is safer to start riding with one foot on the deck and give a kick by other foot to speed up the scooter to 6km/h, then push accelerator and place the other foot on the deck, this is safer and more controlled than pulling off with two feet on the deck as you will have less control and stability with two feet on the deck. Skillfully use the accelerate throttle to speed up or slow down when riding.



3. To stop riding, release the throttle and use the electric brake to gradually coast to a stop then step off the scooter one foot at a time. Be extra cautions when dismounting for the first time.




4. Turn off the scooter when finish using the product by press the power key for 3seconds.



Warning: If scooter has both electric brake and rear physic rear brake, the electric brake is prior to rear brake, which is only used as auxiliary brake when electric brake does not work properly, or in an urgent situation, use the eletric brake and rear brake at the same time.


DO NOT step on rear brake for a long time, or it will break the tyre and fender. Mechanism to reduce speed will get hot from continuous use, do not touch after braking.


4.2 Display Description




| | | |
|--|---------------|--|
| | Power key | Press 2sec to turn it ON / OFF. When the scooter is on, turn on the front light by pressing the power button twice; turn it off by pressing the power button twice again. |
| | Mode key | When the scooter is on, switch the speed modes at low speed, middle speed and high speed by pressing this button |
| | Battery power | 75%-100% power 50%-75% power 25%-50% power 0%-25% power |
| | Speed level | When the icon is white, it is at low speed mode, max speed is 12km/h. When the icon is yellow, it is middle speed mode, max speed is 20km/h. When the icon is red, it is high speed mode, max speed is 25km/h. |
| | Light status | When the icon is on, the front light is turned on, When the icon is off, the front light is turned off. |

4.3 Light description



When the scooter is on, press  twice in short
time to turn on the front light;

When the scooter is on, press  twice in short
time to turn off the front light.

5. SCOOTER SAFETY PRECAUTIONS

Failure to follow any of the following safety precautions can and may lead to damage to your scooter, void your manufacturer warranty, lead to property damage, cause serious bodily injury, and can lead to death.

1. Please wear all appropriate safety and protective gear as previously mentioned in the User Manual before operating the scooter.
2. Make sure to wear comfortable clothes and flat closed toe shoes when operating your scooter.
3. Please carefully read the User Manual, which will assist in explaining the basic working principles and provide tips on how to best enjoy your scooter experience.
4. Do not try to open or modify your scooter, as doing so will void your manufacturer warranty, and may cause failure to your device leading to serious bodily injury or death.
5. Do not use the scooter to place yourself or anyone else and their property in danger.
6. Do not operate the scooter while under the influence of drugs and/or alcohol.
7. Do not operate the scooter when you are restless or sleepy.
8. Use your best judgment to keep yourself out of dangerous situations with your scooter.
9. Do not ride your scooter off of curbs, ramps, or attempt to operate in a skate park, empty pool, or in any ways similar to a skateboard or scooter. **THE SCOOTER IS NOT A SKATEBOARD.**
10. Do not turn sharply, especially at high speeds.
11. Do not abuse your scooter, doing so can damage your unit and cause failure to the operating system leading to injury.
12. Do not drive in or near puddles of water, mud, sand, stones, gravel, debris or near rough and rugged terrain.
13. The scooter can be used on paved roads that are flat and even. If you encounter uneven pavement, please lift your scooter over and past the obstruction.
14. Do not ride in inclement weather: snow, rain, hail, sleet, on icy roads or in extreme heat.
15. Do not ride in or near pools or other large bodies of water.
16. For Bumps and Uneven pavement- Bend your knees when riding on bumpy or uneven pavement to absorb the shock and vibration and help you keep your balance. If you are unsure if you can safely ride on a specific terrain, step off and carry your scooter. **ALWAYS ERR ON THE SIDE OF CAUTION.**

17. Do not attempt to ride over bumps or objects greater than 1.5cm even when prepared and bending your knees.
18. **PAY ATTENTION** - look at where you are riding and be aware of the road conditions, people, places, property and objects around you.
19. Do not operate the scooter in crowded areas.
20. Operate your scooter with extreme caution when indoors, especially around people, property, and narrow spaces like doorways and other narrow spaces.
21. Operate your scooter with extreme consideration for people and property at all times.
22. Do not operate the scooter while talking, texting, or looking at your phone.
23. Do not ride your scooter where it is not permitted.
24. Do not ride your scooter near motor vehicles or on public roads.
25. Do not climb or travel down steep hills with your scooter.
26. The scooter is intended for use by a single individual. **DO NOT** attempt to operate the scooter with two or more people.
27. Do not carry anything while riding the scooter.
28. Individuals with lack of balance should not attempt to operate the scooter.
29. Women who are pregnant or are preparing for pregnancy should not operate the scooter.
30. Young children and the elderly should not operate the scooter without proper instruction and supervision from a Certified scooter trainer.
31. At higher speeds, always take into consideration longer stopping distances.
32. Do not step forward off your scooter.
33. Do not attempt to jump on or off your scooter.
34. Do not attempt any stunts or tricks with your scooter.
35. Do not ride the scooter in dark or poorly lit areas.
36. Do not ride the scooter near or over potholes, cracks or uneven pavement.
37. Do not operate your scooter off-road.
38. Do not exceed the maximum or minimum weight limits.
39. Avoid driving the scooter in unsafe places, including near areas with flammable gas, steam, liquid, dust, fiber, which could cause fire and explosion accidents.

6. Weight and Speed Limitations

PLEASE NOTICE:

Speed and weight limits are set for your own safety. Please do not exceed the limits listed in the User Manual.

6.1 Weight Restrictions: Maximum Weight: 120 kg.

6.2 Speed Limits: Maximum Speed: 25 km/h

7. Operating Range

Please notice the scooter can travel a distance of 13-18 km on a fully charged battery in ideal conditions. The following are some of the major factors that will affect the operating range of your scooter.

Terrain: A smooth, flat surface will increase your driving distance, while driving uphill, as well as rough or uneven terrain will reduce your distance significantly.

Weight: The weight of the user can affect driving distance, a lighter user will have further range than a heavier user.

Ambient temperature: Please ride and store the scooter under recommended temperatures, which will increase driving distance; battery life, and overall performance of your scooter.

Maintenance: Reasonable battery charging and maintenance will increase the distance. Overcharging the battery can reduce range.

Speed and Driving Style: Maintaining a moderate speed will increase your distance; while travelling at high speeds for extended periods, frequent starts, stops, idling, along with frequent acceleration and deceleration will reduce your overall distance.

8. Battery Information and Specifications

This section is intended to provide you basic information about your battery and charger. Please read this section carefully to ensure you. For user safety and to prolong the life of your battery, as well as improve battery performance, please follow these instructions.

When the battery indicator shows low battery capacity, please charge your battery 3 hours utilizing the charger that you received in your scooter package. To fully recharge your battery please follow the instructions under charging your scooter.

8.1 Battery Specifications

| | |
|----------------------|----------------------------|
| Battery | Lithium Battery |
| Charging time | 3 hours |
| Voltage | 36 V |
| Initial Capacity | 5000 mAh |
| Working Temperature | -15°C - 50°C / 5°F - 122°F |
| Charging Temperature | 0°C - 40°C / 32°F - 104°F |
| Storage Time | 6 months |
| Storage Temperature | -20°C - 25°C / -4°F - 77°F |
| Storage Humidity | 5 % -95 % |

8.2 BATTERY WARNING

Failure to follow the Safety Precautions listed in the Battery Warning could lead to serious bodily injury and death. Seek immediate medical attention if you are exposed to any substance that is emitted from the battery.

- Do not attempt to modify, change, or replace your battery.
- Do not use your scooter if the battery begins to emit odor, overheats, or begins to leak.
- Do not touch any leaking materials, or breathe fumes emitted.
- Do not allow children and animals to touch the battery.
- The battery contains dangerous substances, do not open the battery, or insert anything into the battery.

- Please only use the charger provided by scooter.
- Do not attempt to charge the scooter if the battery has discharged or emitted any substances. In that case, the battery should be abandoned for safety.
- Please follow all local, state and federal laws in regards to recycling, handling and disposing of Lithium Ion batteries.
- The scooter should only be shipped in its original packaging.
- Do not throw away your box as you need you scooter packaging for future use.

9. Charging your Scooter

Step 1: Ensure that the charging port is clean and dry.

Step 2: Plug the charger into the power socket, then connect the cable with the power supply (100V~240V; 50,60Hz), make sure the light on the charger is lit GREEN.

Step 3: Male DC connector plug into the charging port of the scooter. The indicator light on the charger should change to RED, indicating that your scooter is now, being charged. When the RED indicator light on your charger turns to GREEN then your scooter is fully charged. A full charge typically occurs within 3 hours.

Step 4: Please unplug the charger from your scooter and from the power outlet.

⚠ IMPORTANT NOTES ABOUT CHARGING

If the green light on your charger does not turn RED when you plug it into your scooter, it could mean you have to check the cables to ensure you have a proper connection; or that your scooter is already fully charged. Push and hold your power button next to the charging port to check the status of your battery in the display.

- Do not overcharge, as this will affect the life of the battery.
- The best charging temperatures are between 0°C - 40°C / 32°F - 104°F. Extreme cold and extreme heat will prevent your battery from charging fully.
- Make sure to unplug your charger before standing on or operating you scooter, as this can be very dangerous.
- Use only the scooter charger that you received in your box.
- If the scooter is powered on when you enter the plug, the Battery Indicator will begin blinking, if the scooter is powered off when you enter the plug, the Battery Indicator will not blink.

⚠ NOTE: Only the indicator light on the charger will tell you the status of the battery during charging.

10. Inspection, Maintenance, and Storage

Your scooter requires routine inspection and maintenance. This chapter describes maintenance steps and important operating tips. Before you perform the following operations, ensure the power and charging cable is disconnected.

Inspecting and Cleaning your scooter

- Disconnect the charger and turn off your scooter.
- Routinely check the body of the scooter and tires for damage or excessive wear.
- Avoid using water or other liquids and cleaners on the scooter for cleaning.
- Wet a clean cloth with clean soapy water, rinse the cloth thoroughly, and wipe the body of the scooter making sure that water does not get into the power button, charging port, the foot mats, or tires.

Storing your scooter

- Fully charge your battery before storing.
- If you are storing your scooter for an extended period of time, please fully charge your scooter at least once every three months.
- If the ambient temperature of the storage location is below 0°, please do not charge. You must bring the scooter into a warmer environment before charging.
- Check under Battery Information and Specifications for more details.
- To prevent dust from getting into your scooter, try wrapping it or sealing it with its original packaging.
- Store your scooter indoors, in a dry and suitable temperature.

⚠ NOTE: Users who disassemble the scooter will forfeit their right of warranty.

11. Scooter Specifications

Features:

- Electric Scooter for Unique Performance
- Portable Folding Design
- 3 Gears and Cruise Control
- Range Up to 15 Miles
- Long-Range Battery
- Braking Systems
- Hand Activated Brakes
- E-ABS Brake
- LED Display
- Easy to Store and Transport
- Suitable for Adults and Kids

What's in the Box:

- (1) Folding Electric Scooter
- (1) AC Charger and Adapter
- (1) Wall Charger



Technical Specs:

- Construction Material: Aluminum and Wood
- Tires: Rubber
- Climbing Degree: 8-10°
- Brake: (Front & Back) E-Brake, (Rear) Fender Brake
- Pedal Board Height: 5.13" -inch
- Resistance: IPX4
- Battery Type: Lithium Battery
- Charging Time: 4 hours
- Motor Rated Power: 250W
- Motor Max Power: 468W
- Power Supply: AC 120V~240V; 50-60Hz
- Voltage: 36 V
- Initial Capacity: 7500 mAh
- Storage Time: 6 months
- Speed: 6.2 mph, 12.4 mph and 15.5 mph (Triple speed modes)
- Max. Load: 264.56 (120 kg.)
- Max. Range: 15-22 km
- Platform Height: 5.12" -inches (130mm)
- Product Dimension (fold): 41.9" x 16.9" x 18.9" -inches
- Product Dimension (unfold): 41.9" x 16.9" x 46.5" -inches



This product can expose you to a chemical or group of chemicals, which may include "Lead (Pb)" which is known in the state of California to cause cancer, birth defects, or other reproductive harm. For more info, go to
WARNING: <https://www.p65warnings.ca.gov/>.



Questions? Issues?

We are here to help!

Email: support@hurtleusa.com