

# JPS04RD Advanced Pogo Stick

## Jump Pogo Stick Jump Counter Pedometer




Advanced Non-Slip Handle



High Elastic and Wear-Resistant Pad



Non-Slip Deck



Fashion protective cover to improve the safety performance of the pogo stick



Core Part:  
High Quality Stainless Steel and Carbon.  
Anti-fatigue Metal Spring



Large and Clear Display Screen, Humanized Button Design.  
ON/OFF, Counter Reset, Select Music Button

### Instruction

1. Before using, please do a comprehensive inspection of the **Jump Pogo Stick**. Make sure the screws are tight and no dirt or gravel on the spring. Be aware of your the anti skid pedal wearing and replace them
2. Grip the non-slip handle with both hands, step on the **Jump Pogo Stick** and then quickly lift up.

### Tips :

1. Beginners are recommended to wear protective gears (armguard, genouillere, elbow pads, helmet). To reduce the risk and incidence of falls, adult supervision is advised
2. Pogo stick jumping is an extreme sport, wear comfortable pants and clothes.
3. Do not play after drinking and avoid playing in a dark place. People who have high blood pressure or heart problems should not play this sport.
4. This new easy to learn and exciting product is for people 6 years old and above. Exercise the abdomen, buttocks, legs and other body parts while having fun. Best exercises to keep you fit, increase height and promotes bone growth.
5. This product should not be exposed to sun and rain to prevent the plastic from aging
6. Do not play close to vehicles, road, street and alleys, pool, valley, stairs, ramps, and lane.

### CAUTION:

1. Change the batteries once they are exhausted.
2. Avoid over charging, lack of charge or over discharge to avoid damaging the battery.
3. Avoid mixing new and old batteries together.
4. Remove the batteries if you are not going to use the product for a long time.
5. The storage battery should be kept with full power and recharge it every month to avoid circuit board being acidified.
6. DO NOT throw the battery into a fire or expose to heat
7. The storage battery should be replaced if the battery cover is broken or leaking.
8. If any leaked fluid gets on your skin or clothes, wash it off immediately