

# FRONT



# BACK

**nutrichef**

#### **BEFORE USING:**

- Clean the bakeware mold before using it the first time.
- Grease the inside with some oil, butter or margarine before putting it in the oven.

#### **CLEANING:**

- Although dishwasher safe, we recommend cleaning by hand.
- Wash with warm water, non-abrasive soap, and nonmetallic sponge or cloth. Do not use baking soda, detergents, or other harsh soaps or solutions.

#### **IMPORTANT SAFEGUARDS:**

- Cook in a static, a ventilated or a gas oven.
- Keep clear from a direct contact with heat or flames.
- To avoid scratches, use nonmetallic utensils made of plastic, silicone, wood, or bamboo.
- Do **NOT** put an empty mold in the oven.
- Do **NOT** use in microwave.
- Do **NOT** go over a maximum temperature of 230°C.
- Let it cool down for a few minutes before demolding.

Questions/Concerns: [jb@pyleusa.com](mailto:jb@pyleusa.com)

#NutriChefKitchen

