















РСВ4ВК

MOUNTING

PCB4WT

Features:

- Full Range Mini Speaker System
- Great for Home Theater Applications
- Video Shielded
- 4" Paper Cone Driver
- Power Handling: 200 Watts Peak
- Frequency Response: 80 Hz 18 kHz
- 8 Ohm Impedance
- Dimensions: 4.8" (H) x 4.8" (W) x 5.2" (D)

Installation

MOUNTING THE BRACKET

Pull out half of the key at the back of the speaker, then insert the support through the hole on the key, and the support is fixed to the wall.

FINAL ADJUSTMENTS

- 1. After checking that the speaker is in phase and works correctly, angle the speaker for the best sound.
- 2. Hand-tighten the bracket knobs only. Power tools may over-tighten the knob and strip the threads of the insert.
- 3. Check that the entire installation is safe and secure.

Connecting Your Speakers

Connecting the speakers to your amplifier or receiver.

- First, turn your amplifier off to avoid damage which may result from accidental shorting of the speaker leads.
- Correct phase polarity is critical for proper stereo imaging and bass performance.
 The red (+) terminal on your amplifier or receiver must be connected to the red (+) terminal on your speaker; the same applies to the black (-) terminal.
- Connect one loudspeaker at a time to ensure proper connection of left and right channels. Make sure all wires are firmly fastened.
- If you notice a high level of bass or central image focus, double-check your connections for proper polarity.



NEGATIVE TERMINAL

(BLACK)

CONNECT NEGATIVE WIRE TO NEGATIVE TERMINAL OF YOUR AMP OR RECEIVER. CONNECT POSITIVE WIRE TO POSITIVE TERMINAL OF YOUR AMP OR RECEIVER.

POSITIVE TERMINAL

(RED)



Questions or Comments? We are here to help! Phone: 1.718.535.1800 PyleUSA.com/ContactUs

California Prop 65 Warning

This product can expose you to chemicals, which is known to the state of California to cause cancer birth defects and other reproductive harm. Do not ingest.

For more info go to: www.P65warnings.ca.gov